



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED

By Carol Day at 3:35 pm, Mar 31, 2014

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 097438	PRINTER SN 096.3580.921	DATE OF INSPECTION 03/18/2014
-----------------------------	----------------------------	----------------------------------

LOCATION OF INSTRUMENT (STREET AND CITY) 700 West Main Street, Willow Springs	TIME OF INSPECTION 4:02 am
--	-------------------------------

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

TEMPERATURE OF ALCO SENSOR (10°C - 40°C) 24

PRINTER WORKING PROPERLY

TIME AND DATE DISPLAYING PROPERLY 03/18/14 04:02

BREATH ALCOHOL ACCURACY STANDARDS

SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER Guth Labs LOT # 13280 EXP. DATE 10/16/2015

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0c SIMULATOR SN SD2239 SIMULATOR EXP DATE 06/06/2014

CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 ← .100

TEST 2 ← .099

TEST 3 ← .099

RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
(DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

Replaced battery.
Adjusted time for daylight savings time.

INSPECTING OFFICER

SIGNATURE 	PRINT NAME Bryan Wickham
---------------	-----------------------------

TYPE II PERMIT NUMBER/EXPIRATION DATE 220146 06/25/2014	TELEPHONE NUMBER (417) 469-3158
--	------------------------------------

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
2875 James Boulevard
Poplar Bluff, MO 63901

**GUTH LABORATORIES, INC.**

690 NORTH 87th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-664-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 13280 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 18, 2013, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1217% (w/vol) ethyl alcohol. The expiration date for this lot number is October 16, 2015 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Tracability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

AS IV Serial no: 097438
Version no: 084C

TEST RECORD 00350

Temp Date Time 210L ^{9/}

Air Blank: 03/18/14 04:02 .000

Calibration Check: 24 03/18/14 04:02 .100

Subject Name

Subject I.D.

Operator Name, I.D.

B. Wickham 405
Location

AS IV Serial no: 097438
Version no: 084C

TEST RECORD - REPRINT

TEST RECORD 00351

Temp Date Time 210L ^{9/}

Air Blank: 03/18/14 04:09 .000

Calibration Check: 25 03/18/14 04:09 .099

Subject Name

Subject I.D.

Operator Name, I.D.

B. Wickham 405
Location

AS IV Serial no: 097438
Version no: 084C

TEST RECORD 00352

Temp Date Time 210L ^{9/}

Air Blank: 03/18/14 04:11 .000

Calibration Check: 26 03/18/14 04:11 .099

Subject Name

Subject I.D.

Operator Name, I.D.

B. Wickham 405
Location

AS IV Serial no: 097438
Version no: 084C

TEST RECORD 00353

Temp Date Time 210L ^{9/}

Void: RFI 12 03/18/14 04:12

Subject Name

Subject I.D.

Operator Name, I.D.

B. Wickham 405
Location

State of Missouri
DEPARTMENT OF HEALTH



P E R M I T
TYPE II



BRYAN WICKHAM

Is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV W/PRINTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1988.

Date 06/25/2012

Number 220146

Expires 06/25/2014

MO 680-0771 (7-88)

Director of State Public Health Laboratory

Director, Department of Health

Lab. 4 (R7-88)