



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED
By Carol Day at 4:12 pm, Apr 23, 2014
REPORT #1

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 105451	PRINTER SN 096.3580.925	DATE OF INSPECTION 04/15/2014
-----------------------------	----------------------------	----------------------------------

LOCATION OF INSTRUMENT (STREET AND CITY) 301 S Main St, Excelsior Springs	TIME OF INSPECTION 1:09 pm
--	-------------------------------

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

<input checked="" type="checkbox"/> SIMULATOR SOLUTION	<input type="checkbox"/> COMPRESSED ETHANOL-GAS MIXTURE
--	---

<input checked="" type="checkbox"/> STANDARD SUPPLIER <u>GUTH</u>	LOT # <u>13210</u>	EXP. DATE <u>07/29/2015</u>
---	--------------------	-----------------------------

<input checked="" type="checkbox"/> SIMULATOR TEMPERATURE (34°C ± 0.2°C) <u>34.0</u>	SIMULATOR SN <u>358440</u>	SIMULATOR EXP DATE <u>06/17/2014</u>
--	----------------------------	--------------------------------------

- CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)
 - 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
 - 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
 - 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 <u>.099</u>	TEST 2 <u>.099</u>	TEST 3 <u>.099</u>
--------------------	--------------------	--------------------

- RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	<u>1</u>	(.0-.04)	<u>0</u>	(.05-.09)	<u>0</u>	(.10-.14)	<u>1</u>	(.15-.19)	<u>3</u>	(OVER .19)	<u>0</u>
----------	----------	----------	----------	-----------	----------	-----------	----------	-----------	----------	------------	----------

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

SPECTING OFFICER	
SIGNATURE 	PRINT NAME Sgt. Brian K Kennedy
PERMIT NUMBER/EXPIRATION DATE 30073 04/26/2015	TELEPHONE NUMBER (816) 630-2000
Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office 2875 James Boulevard Poplar Bluff, MO 63901	

**GUTH LABORATORIES, INC.**

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 13210 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on July 31, 2013, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1216% (w/vol) ethyl alcohol. The expiration date for this lot number is July 29, 2015 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Certified Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

1751 RECORD 90200
 Date: 04/15/14 13:11:00
 Calibration Code: 25 04/15/14 13:11:00
 Subject: M
MONTHLY MAINT.
 Subject: M

Sgt. BK KENNEDY 9A
 301 S. MAIN

1751 RECORD 90200
 Date: 04/15/14 13:11:00
 Calibration Code: 25 04/15/14 13:11:00
 Subject: M
MONTHLY MAINT.
 Subject: M

Sgt. BK KENNEDY 9A
 301 S. MAIN

1751 RECORD 90200
 Date: 04/15/14 13:11:00
 Calibration Code: 25 04/15/14 13:11:00
 Subject: M
MONTHLY MAINT.
 Subject: M

Sgt. BK KENNEDY
 301 S. MAIN

1751 RECORD 90200
 Date: 04/15/14 13:11:00
 Calibration Code: 25 04/15/14 13:11:00
 Subject: M
MONTHLY MAINT.
 Subject: M

Sgt. BK KENNEDY
 301 S. MAIN



STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



**PERMIT
TYPE II**

BRIAN K KENNEDY

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV W/PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 04/26/2013

NUMBER 230073

EXPIRES 04/26/2015

MO 580-0771 (6-10)

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

Acting Director

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

LAB-4 (RS-10)