



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED
 By Carol Day at 10:52 am, Nov 25, 2014

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 108268	PRINTER SN 099.3586.791	DATE OF INSPECTION 11-25-2014
LOCATION OF INSTRUMENT (STREET AND CITY) 1781 Zumbel, St. Charles		TIME OF INSPECTION 0843 hrs

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

<input checked="" type="checkbox"/> DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)	OK
<input checked="" type="checkbox"/> TEMPERATURE OF ALCO SENSOR (10°C - 40°C)	OK
<input checked="" type="checkbox"/> PRINTER WORKING PROPERLY	OK
<input checked="" type="checkbox"/> TIME AND DATE DISPLAYING PROPERLY	OK

BREATH ALCOHOL ACCURACY STANDARDS

<input checked="" type="checkbox"/> SIMULATOR SOLUTION	<input type="checkbox"/> COMPRESSED ETHANOL-GAS MIXTURE
<input checked="" type="checkbox"/> STANDARD SUPPLIER Guth Laboratories	LOT # 14030 EXP. DATE 1/20/2016
<input checked="" type="checkbox"/> SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34°C	SIMULATOR SN S02248 SIMULATOR EXP DATE 1/17/2015

CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
 Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

<input checked="" type="checkbox"/> 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
<input type="checkbox"/> 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
<input type="checkbox"/> 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 = .100 %	TEST 2 = .100	TEST 3 = .102
------------------------	----------------------	----------------------

RFI DETECTOR OPERATING **OK**

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0 (0-.04)	0 (.05-.09)	0 (.10-.14)	0 (.15-.19)	0 (OVER .19)
----------	------------------	--------------------	--------------------	--------------------	---------------------

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

INSPECTING OFFICER	
SIGNATURE P.O. Daniel Allen 196	PRINT NAME P.O. Daniel Allen 196
TYPE II PERMIT NUMBER/EXPIRATION DATE 230256 11/18/2015	TELEPHONE NUMBER (636) 949-3300

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Boulevard
 Poplar Bluff, MO 63901



GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 14030 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **January 22, 2014**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.1215%** (w/vol) ethyl alcohol. The expiration date for this lot number is **January 20, 2016** at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of **0.100 g/2.10L +/- 3%**.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

AS IV Serial no: 108268
Version no: 532B

TEST RECORD 00013

Temp Date Time ^{s/} 210L

Air Blank:
11/25/14 08:45 .000
Calibration Check:
26 11/25/14 08:45 .102

Subject Name

Subject I.D.

Operator Name, I.D.

Allen 196
Location
1781 Zumbach
St. Charles, Mo.

AS IV Serial no: 108268
Version no: 532B

TEST RECORD 00011

Temp Date Time ^{s/} 210L

Air Blank:
11/25/14 08:43 .000
Calibration Check:
25 11/25/14 08:43 .100

Subject Name

Subject I.D.

Operator Name, I.D.

Allen 196
Location
1781 Zumbach
St. Charles, Mo.

AS IV Serial no: 108268
Version no: 532B

TEST RECORD 00014

Temp Date Time ^{s/} 210L

VOID: RFI
12 11/25/14 08:47

Subject Name

Subject I.D.

Operator Name, I.D.

Allen 196
Location
1781 Zumbach
St. Charles, Mo.

AS IV Serial no: 108268
Version no: 532B

TEST RECORD 00012

Temp Date Time ^{s/} 210L

Air Blank:
11/25/14 08:44 .000
Calibration Check:
26 11/25/14 08:44 .100

Subject Name

Subject I.D.

Operator Name, I.D.

Allen 196
Location
1781 Zumbach
St. Charles, Mo.