



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
 BREATH ALCOHOL PROGRAM
DATAMASTER MAINTENANCE REPORT

RECEIVED 5/14/14-CD

REPORT #6

Complete this report at the time of the regular monthly preventive maintenance check (not to exceed 30 days). Complete this report whenever the instrument is serviced or repaired and whenever it is placed in service. Retain the original and send a copy within 15 days to the Breath Alcohol Program, DHSS.

REVIEWED
 By Carol Day at 10:49 am, May 29, 2014

DATAMASTER SN 204068	NAME OF AGENCY Missouri State Highway Patrol	DATE OF INSPECTION 05/07/2014
LOCATION OF INSTRUMENT (STREET AND CITY) Pulaski County Sheriff's Dept, 301 West Historic Route 66, Waynesville		TIME OF INSPECTION 10:03 pm

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

<input checked="" type="checkbox"/> DIAGNOSTIC CHECK (PRINTOUT ATTACHED)	DATE AND TIME (from printout) 05/07/14 22:03
<input checked="" type="checkbox"/> COMPUTER	<input checked="" type="checkbox"/> DETECTOR
<input checked="" type="checkbox"/> PROGRAM	<input checked="" type="checkbox"/> FILTERS
<input checked="" type="checkbox"/> HEATERS SAMPLE CHAMBER 50 °C	<input checked="" type="checkbox"/> QUARTZ STANDARD
<input checked="" type="checkbox"/> FLOW DETECTOR	<input checked="" type="checkbox"/> CALIBRATION
<input checked="" type="checkbox"/> PUMP HIGH SPEED	<input checked="" type="checkbox"/> PRINTER

INDICATOR LIGHTS

SIMULATOR SOLUTION SUPPLIER Guth Laboratories Inc LOT # 13290 EXP. DATE 10/29/2015

SIMULATOR TEMP (34°C ± 0.2°C) 34 °C SIMULATOR SN G6775 EXP. DATE 03/03/2015

CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE
 0.080% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE
 0.040% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE

TEST 1 .104	TEST 2 .104	TEST 3 .104
-------------	-------------	-------------

PERFORM R.F.I. TEST (PRINTOUT ATTACHED)

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
 (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	2	(.15-.19)	0	OVER .19	2
----------	---	---------	---	-----------	---	-----------	---	-----------	---	----------	---

LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR MODIFICATION THAT WAS MADE TO RESTORE THE INSTRUMENT TO OPERATE SATISFACTORILY AND WITHIN ESTABLISHED LIMITS (USE OTHER SIDE IF NECESSARY).

Operating within MODHSS specifications
 Instrument moved to new location
 Set clock

INSPECTING OFFICER	
SIGNATURE <i>K. G. Baldwin</i>	PRINT FULL NAME Kenneth A. Baldwin
TYPE II PERMIT NUMBER/EXPIRATION DATE 230081 05/10/2015	TELEPHONE NUMBER (573) 368-2345

RETURN COMPLETED REPORT TO THE: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Blvd.
 Poplar Bluff, MO 63901



GUTH LABORATORIES, INC.

590 NORTH 6TH STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number **13290** of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **October 31, 2013**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.1202%** (w/vol) ethyl alcohol. The expiration date for this lot number is **October 29, 2015** at 11:59 PM.

When used in a calibrated Simulator, operating at **34°C +/- .2°C**, this solution will give a breath alcohol analysis instrument reading of **0.100 g/210L +/- 3%**.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM



PERMIT
TYPE II

KENNETH A BALDWIN

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 05/10/2013

NUMBER 230081

EXPIRES 05/10/2015

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

Acting Director

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL
BAC DATAMASTER SERIAL NUMBER 204068
05/07/14

PROJECT TIME: 22:00
SUBJECT NAME:
TEST:
DOB: 01/02/55 SEX: M
STATE/D.O.C. # MO-000000000
ARRESTING OFFICER:
BALDWIN, P. A.
OFFICER I.D.# 184
TESTING OFFICER:
SAME
OFFICER I.D.# 184
PERMIT NUMBER: 20000
EXPIRATION DATE: 05/10/15
MISCELLANEOUS DATA:

--- BREATH ANALYSIS ---

BLANK TEST	LOGS	RESULTS
INTERNAL STANDARD	VERIFIED	RESULTS
FIELD INTERFERENCE		

Operator Signature

