



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
 BREATH ALCOHOL PROGRAM
DATAMASTER MAINTENANCE REPORT

RECEIVED
 By Carol Day at 1:12 pm, Apr 25, 2014

Complete this report at the time of the regular monthly preventive maintenance check (not to exceed 35 days).
 Complete this report whenever the instrument is serviced or repaired and whenever it is placed into service.
 Retain the original and send a copy within 15 days to the Breath Alcohol Program, DHSS.

DATAMASTER SN 931097	NAME OF AGENCY Lawson Police Department	DATE OF INSPECTION 04/19/2014
LOCATION OF INSTRUMENT (STREET AND CITY) 104 W Third Street, Lawson MO 64062		TIME OF INSPECTION 2328

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

<input checked="" type="checkbox"/> DIAGNOSTIC CHECK (PRINTOUT ATTACHED)	DATE AND TIME (from printout) 04/19/14 23:29
<input checked="" type="checkbox"/> COMPUTER	<input checked="" type="checkbox"/> DETECTOR
<input checked="" type="checkbox"/> PROGRAM	<input checked="" type="checkbox"/> FILTERS
<input checked="" type="checkbox"/> HEATERS SAMPLE CHAMBER _____ °C	<input checked="" type="checkbox"/> QUARTZ STANDARD
<input checked="" type="checkbox"/> FLOW DETECTOR	<input checked="" type="checkbox"/> CALIBRATION
<input checked="" type="checkbox"/> PUMP HIGH SPEED	<input checked="" type="checkbox"/> PRINTER

INDICATOR LIGHTS

SIMULATOR SOLUTION SUPPLIER **RepCo Marketing** LOT # **13002** EXP. DATE **6-19-15**

SIMULATOR TEMP (34°C ± 0.2°C) **34.0** °C SIMULATOR SN **DR5392** EXP. DATE **01/10/2015**

CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE
 0.080% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE
 0.040% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE

TEST 1 .101	TEST 2 .101	TEST 3 .101
--------------------	--------------------	--------------------

PERFORM R.F.I. TEST (PRINTOUT ATTACHED)

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
 (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	(0-.04)	(.05-.09)	(.10-.14)	(.15-.19)	OVER .19
----------	---------	-----------	-----------	-----------	----------

LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR MODIFICATION THAT WAS MADE TO RESTORE THE INSTRUMENT TO OPERATE SATISFACTORILY AND WITHIN ESTABLISHED LIMITS (USE OTHER SIDE IF NECESSARY).
Conforms with DoHSS standards

INSPECTING OFFICER	
SIGNATURE Cpt. Bruce Sumner 202	PRINT FULL NAME
TYPE II PERMIT NUMBER/EXPIRATION DATE	TELEPHONE NUMBER

RETURN COMPLETED REPORT TO THE:
 Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Blvd.
 Poplar Bluff, MO 63901

CERTIFICATE OF ANALYSIS

MANUFACTURER AND SUPPLIER: RepCo Marketing, Inc.

LOT NUMBER: 13002

EXPIRATION DATE: June 19, 2015 at 11:59 p.m.

RepCo Marketing, Inc. certifies the following:

RepCo Marketing, Inc. manufactured, tested and supplied Lot Number 13002 of Alcohol Certified Solution for simulators. Random samples of said lot number were analyzed by an independent laboratory utilizing a gas chromatograph and found to contain .1217 gms/dl +/-0.003 gms/dl wt/vol ethanol (95% Confidence).

The alcohol and distilled water used in the solution were found to be free of any interfering substance.

This solution will produce a vapor alcohol value of .100 +/-3% gms/210L Breath when heated to 34 Degrees Celsius +/-0.2 Degrees Celsius in a simulator (95% Confidence).

The date of manufacture for this lot number is June 20, 2013
The expiration date for this lot number is June 19, 2015 at
11:59 p.m.

This document is a true representation of the original Certificate of Analysis.



Cecil B. Garner, President
RepCo Marketing, Inc.

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI
LAWSON POLICE DEPARTMENT

BAC DATA MASTER SERIAL NUMBER 931097
04/19/14

ARREST TIME: 23:15

SUBJECT NAME:

RFI/TEST

DOB: 10/10/10 SEX: M

STATE/D.L.: MO/1234567

ARRESTING OFFICER:

SUMMA/BRUCE/A

OFFICER I.D.: 202

TESTING OFFICER:

SUMMA/BRUCE/A

OFFICER I.D.: 202

PERMIT NUMBER: 220319

EXPIRATION DATE: 09/28/14

MISCELLANEOUS DATA:

RFI TEST

--- BREATH ANALYSIS ---

BLANK TEST .000 23:41

INTERNAL STANDARD VERIFIED 23:41

RADIO INTERFERENCE

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI
LAWSON POLICE DEPARTMENT

BAC DATA MASTER SERIAL NUMBER 931097
04/19/14

TESTING OFFICER:

SUMMA/BRUCE/A

OFFICER I.D.: 202

PERMIT NUMBER: 220319

EXPIRATION DATE: 09/28/14

MISCELLANEOUS DATA:

--- SUPERVISOR MODE ---

BLANK TEST .000 23:33

INTERNAL STANDARD VERIFIED 23:33

EXTERNAL STANDARD .101 23:33

BLANK TEST .000 23:34

EXTERNAL STANDARD .101 23:35

BLANK TEST .000 23:35

EXTERNAL STANDARD .101 23:36

BLANK TEST .000 23:36

N = 3

SIM. = .1

AVG. = .101

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI
LAWSON POLICE DEPARTMENT

BAC DATA MASTER SERIAL NUMBER 931097
04/19/14
23:29

--- DIAGNOSTIC CHECK ---

COMPUTER: OKAY

PROGRAM (04-07-2009): OKAY

HEATERS

SAMPLE CHAMBER: 49c

FLOW DETECTOR: OKAY

PUMP

HIGH SPEED: OKAY

DETECTOR: OKAY

FILTERS: OKAY

QUARTZ STANDARD: OKAY

CALIBRATION: OKAY

PRINTER TEST

! "#\$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJK
HIJKLMNOPQRSTUVWXYZ[\]^_`abcdefshijklmnop
q-rstuvwxyz{|}~*

OPERATOR SIGNATURE *G.P. Bruce Summa 202*

ID STK # REORDER ALL SUPPLIES FROM N.P.A.S.
2260 NORTH MAIN, MANSFIELD, OH 44903 419-526-6727 (NPAS)

OPERATOR SIGNATURE *G.P. Bruce Summa 202*

CARD STK # REORDER ALL SUPPLIES FROM N.P.A.S.
2260 NORTH MAIN, MANSFIELD, OH 44903 419-526-6727 (NPAS)

OPERATOR SIGNATURE *G.P. Bruce Summa 202*

CARD STK # REORDER ALL SUPPLIES FROM N.P.A.S.
2260 NORTH MAIN, MANSFIELD, OH 44903 419-526-6727 (NPAS)

State of Missouri
DEPARTMENT OF HEALTH



P E R M I T
TYPE II



BRUCE SUMMA

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

Date 09/28/2012

Number 220319

Expires 09/28/2014

Director of State Public Health Laboratory

Director, Department of Health