



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED

By Carol Day at 12:42 pm, Mar 27, 2015

Complete this report in duplicate at the time of the regular monthly preventative maintenance. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 092835	PRINTER SN 071.3383.132	DATE OF INSPECTION 03/27/2015
LOCATION OF INSTRUMENT (STREET AND CITY) 4525 Downs Drive St. Joseph, MO 64507		TIME OF INSPECTION 10:20 am

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

TEMPERATURE OF ALCO SENSOR (10°C - 40°C)

PRINTER WORKING PROPERLY

TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER RepCo Marketing LOT # 13002 EXP. DATE 06/19/2015

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIMULATOR SN SD3506 SIMULATOR EXP DATE 12/17/2015

CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
- 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
- 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 → .102

TEST 2 → .101

TEST 3 → .101

RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
 (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

Instrument operating within the limits set forth by the Missouri Department of Health and Senior Services. RepCo Marketing Inc. .100 Solution Lot # 13002 expires 06/19/2015. Date and Time updated do to daylight savings.

INSPECTING OFFICER

SIGNATURE 	PRINT NAME James Bench
TYPE II PERMIT NUMBER/EXPIRATION DATE 240032 02/11/2016	TELEPHONE NUMBER (816) 271-4438

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Boulevard
 Poplar Bluff, MO 63901

AS IV Serial no: 092835
Version no: 532B

TEST RECORD 00057

Temp Date Time 210L
9/

Air Blank:
03/27/15 10:23 .000
Calibration Check:
26 03/27/15 10:23 .102

Subject Name

Subject I.D.

Operator Name, I.D.

Location
J. Bels 2117

4525 Downs Dr.

St. Joseph no 64507

AS IV Serial no: 092835
Version no: 532B

TEST RECORD 00058

Temp Date Time 210L
9/

Air Blank:
03/27/15 10:24 .000
Calibration Check:
26 03/27/15 10:24 .101

Subject Name

Subject I.D.

Operator Name, I.D.

Location
J. Bels 2117

4525 Downs Dr.

St. Joseph no 64507

AS IV Serial no: 092835
Version no: 532B

TEST RECORD 00059

Temp Date Time 210L
9/

Air Blank:
03/27/15 10:26 .000
Calibration Check:
27 03/27/15 10:26 .101

Subject Name

Subject I.D.

Operator Name, I.D.

Location
J. Bels 2117

4525 Downs Dr.

St. Joseph no 64507

AS IV Serial no: 092835
Version no: 532B

TEST RECORD 00060

Temp Date Time 210L
9/

NOTE: RFI
12 03/27/15 10:27

Subject Name

Subject I.D.

Operator Name, I.D.

Location
J. Bels 2117

4525 Downs Dr.

St. Joseph no 64507



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 078389	PRINTER SN 071.3383.132	DATE OF INSPECTION 03/27/2015
LOCATION OF INSTRUMENT (STREET AND CITY) 4525 Downs Drive St. Joseph, MO 64507		TIME OF INSPECTION 9:44 am

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

TEMPERATURE OF ALCO SENSOR (10°C - 40°C)

PRINTER WORKING PROPERLY

TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER RepCo Marketing Inc. LOT # 13002 EXP. DATE 06/19/2015

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIMULATOR SN SD3506 SIMULATOR EXP DATE 12/17/2015

CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
 Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
- 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
- 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 .103

TEST 2 .103

TEST 3 .103

RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
 (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

Instrument operating within the limits set forth by the Missouri Department of Health and Senior Services. RepCo Marketing Inc. .100 Solution lot # 13002 expires 06/19/2015. Time and date updated do to daylight savings.

INSPECTING OFFICER

SIGNATURE 	PRINT NAME James Bench
TYPE II PERMIT NUMBER/EXPIRATION DATE 240032 02/11/2016	TELEPHONE NUMBER (816) 271-4438

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Boulevard
 Poplar Bluff, MO 63901

AS IU Serial no: 078389
Version no: 532B

TEST RECORD 00067

Temp Date Time 210L 9/

Air Blank: 03/27/15 09:58 .000
Calibration Check: 28 03/27/15 09:58 .103

Subject Name

Subject I.D.

Operator Name, I.D.

Location
S. Bah 2117

4525 Down's Dr.

St. Joseph Mo 64507

AS IU Serial no: 078389
Version no: 532B

TEST RECORD 00068

Temp Date Time 210L 9/

Air Blank: 03/27/15 10:00 .000
Calibration Check: 29 03/27/15 10:00 .103

Subject Name

Subject I.D.

Operator Name, I.D.

Location
S. Bah 2117

4525 Down's Dr.

St. Joseph Mo 64507

AS IU Serial no: 078389
Version no: 532B

TEST RECORD 00069

Temp Date Time 210L 9/

Air Blank: 03/27/15 10:03 .000
Calibration Check: 29 03/27/15 10:03 .103

Subject Name

Subject I.D.

Operator Name, I.D.

Location
S. Bah 2117

4525 Down's Dr.

St. Joseph Mo 64507

AS IU Serial no: 078389
Version no: 532B

TEST RECORD 00070

Temp Date Time 210L 9/

VOID: RFI
12 03/27/15 10:05

Subject Name

Subject I.D.

Operator Name, I.D.

Location
S. Bah 2117

4525 Down's Dr.

St. Joseph Mo 64507

CERTIFICATE OF ANALYSIS

MANUFACTURER AND SUPPLIER: RepCo Marketing, Inc.

LOT NUMBER: 13002

EXPIRATION DATE: June 19, 2015 at 11:59 p.m.

RepCo Marketing, Inc. certifies the following:


RepCo Marketing, Inc. manufactured, tested and supplied Lot Number 13002 of Alcohol Certified Solution for simulators. Random samples of said lot number were analyzed by an independent laboratory utilizing a gas chromatograph and found to contain .1217 gms/dl +/- .003 gms/dl wt/vol ethanol (95% Confidence).

The alcohol and distilled water used in the solution were found to be free of any interfering substance.

This solution will produce a vapor alcohol value of .100 +/- 3% gms/210L Breath when heated to 34 Degrees Celsius +/- 0.2 Degrees Celsius in a simulator (95% Confidence).

The date of manufacture for this lot number is June 20, 2013
The expiration date for this lot number is June 19, 2015 at 11:59 p.m.

This document is a true representation of the original Certificate of Analysis.



Cecil B. Garner, President
RepCo Marketing, Inc.



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

2

PERMIT
TYPE II
JAMES E BENCH

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 2/11/2014

NUMBER 240032

EXPIRES 2/11/2016

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.



Operator BENCH, JAMES
 Permit No 240032
 Date Issued 2/11/2014 Date Expires 2/11/2016