



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES  
 STATE PUBLIC HEALTH LABORATORY  
**ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT**

**RECEIVED**  
 By Carol Day at 2:47 pm, Apr 19, 2016

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN #099362	PRINTER SN #097.3584.337	DATE OF INSPECTION 04/17/2016
LOCATION OF INSTRUMENT (STREET AND CITY) 709 West Main Street, Greenwood, MO 64034		TIME OF INSPECTION 8:48 pm

**CHECKLIST:** Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

**BREATH ALCOHOL ACCURACY STANDARDS**

- SIMULATOR SOLUTION  COMPRESSED ETHANOL-GAS MIXTURE
- STANDARD SUPPLIER Guth Laboratories Inc. LOT # 15120 EXP. DATE 04/29/2017
- SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIMULATOR SN #SD2285 SIMULATOR EXP DATE 01/14/2017

- CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)  
 Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)
  - 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
  - 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
  - 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 → .099	TEST 2 → .099	TEST 3 → .100
---------------	---------------	---------------

- RFI DETECTOR OPERATING

**INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)**

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

**INSPECTING OFFICER**

SIGNATURE Tony W. White #337/150	PRINT NAME Tony W. White
TYPE II PERMIT NUMBER/EXPIRATION DATE #240220 Exp. Date: 04-30-2016	TELEPHONE NUMBER (816) 537-5020

**Return completed report to the:** Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office  
 2875 James Boulevard  
 Poplar Bluff, MO 63901

Test #1

AS IV Serial no: 099362  
Version no: 532B

TEST RECORD 00364

Temp Date Time 210L

Air Blank:  
04/17/16 20:48 .000  
Calibration Check:  
27 04/17/16 20:48 .099

Subject Name  
Tony White  
Subject I.D.

Operator Name, I.D.

Location  
GPD

Test #2

AS IV Serial no: 099362  
Version no: 532B

TEST RECORD 00365

Temp Date Time 210L

Air Blank:  
04/17/16 20:50 .000  
Calibration Check:  
27 04/17/16 20:50 .099

Subject Name  
Tony White  
Subject I.D.

Operator Name, I.D.

Location  
GPD

Test #3

AS IV Serial no: 099362  
Version no: 532B

TEST RECORD - REPRINT

TEST RECORD 00366

Temp Date Time 210L

Air Blank:  
04/17/16 20:51 .000  
Calibration Check:  
28 04/17/16 20:51 .100

Subject Name  
Tony White  
Subject I.D.

Operator Name, I.D.

Location  
GPD

RFI

AS IV Serial no: 099362  
Version no: 532B

TEST RECORD 00367

Temp Date Time 210L

UGID: RFI  
12 04/17/16 20:54

Subject Name  
Tony White  
Subject I.D.

Operator Name, I.D.

Location  
GPD

Cpl. Hein



STATE OF MISSOURI  
DEPARTMENT OF HEALTH AND SENIOR SERVICES  
BREATH ALCOHOL PROGRAM

2

**PERMIT**  
**TYPE II**  
**TONY WHITE**

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

**ALCO-SENSOR IV WITH PRINTER**

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 4/30/2014

NUMBER 240220

EXPIRES 4/30/2016

MO 580-0771 (8-10)

\_\_\_\_\_  
DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

\_\_\_\_\_  
DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

LAB-4 (R6-10)

 **STATE OF MISSOURI**  
DEPARTMENT OF HEALTH AND SENIOR SERVICES  
BREATH ALCOHOL PROGRAM

**INSTRUMENT OPERATOR CARD**

*The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.*



Operator **WHITE, TONY**  
Permit No **240220**  
Date Issued **4/30/2014** Date Expires **4/30/2016**



## GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4811 • TELEPHONE: 717-564-5470

### CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number **15120** of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **May 4, 2015**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.1209%** (w/vol) ethyl alcohol. The expiration date for this lot number is **April 29, 2017** at 11:59 PM.

When used in a calibrated Simulator, operating at  $34^{\circ}\text{C} \pm .2^{\circ}\text{C}$ , this solution will give a breath alcohol analysis instrument reading of **0.100 g/210L  $\pm$  3%**.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President  
GUTH LABORATORIES, INC.

***NIST Traceability:***

*Testing was conducted using Cerilliant Reference Standard lot number FN08051301 whose values are traceable to NIST.*

*All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.*