



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED
 By Brian Lutmer at 11:57 am, Jan 14, 2016

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 107460	PRINTER SN 099.3586.711	DATE OF INSPECTION 01/13/2016
LOCATION OF INSTRUMENT (STREET AND CITY) 461 W. Arrow St., Marshall		TIME OF INSPECTION 5:10 pm

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

TEMPERATURE OF ALCO SENSOR (10°C - 40°C)

PRINTER WORKING PROPERLY

TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER Guth Inc LOT # 15120 EXP. DATE 04/29/2017

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIMULATOR SN SD2277 SIMULATOR EXP DATE 10/07/2016

CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
- 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
- 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 .100

TEST 2 .100

TEST 3 .099

RFI DETECTOR OPERATING

**INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
 (DO NOT INCLUDE SELF-ADMINISTERED TESTS)**

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

N/A

INSPECTING OFFICER

SIGNATURE 	PRINT NAME John J. Coney
TYPE II PERMIT NUMBER/EXPIRATION DATE 240196 / 04-40-2016	TELEPHONE NUMBER (660) 886-7411

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Boulevard
 Poplar Bluff, MO 63901

AS IV Serial no: 187460
Version no: 532B

TEST RECORD 00312

Temp	Date	Time	%	210L
------	------	------	---	------

Air Blank:
01/13/16 17:01 .000
Calibration Check:
24 01/13/16 17:01 .099

Subject Name

Subject I.D.

Operator Name, I.D.

John J. Coney #118

Location

Marshall P.D.

AS IV Serial no: 187460
Version no: 532B

TEST RECORD 00311

Temp	Date	Time	%	210L
------	------	------	---	------

Air Blank:
01/13/16 16:59 .000
Calibration Check:
23 01/13/16 16:59 .100

Subject Name

Subject I.D.

Operator Name, I.D.

John J. Coney #118

Location

Marshall P.D.

AS IV Serial no: 187460
Version no: 532B

TEST RECORD 00310

Temp	Date	Time	%	210L
------	------	------	---	------

Air Blank:
01/13/16 16:58 .000
Calibration Check:
23 01/13/16 16:58 .100

Subject Name

Subject I.D.

Operator Name, I.D.

John J. Coney #118

Location

Marshall P.D.

AS IV Serial no: 187460
Version no: 532B
TEST RECORD 00313
Temp Date Time %
210L
VOID: RFI
12 01/13/16 17:03
Subject Name
Subject I.D.
Operator Name, I.D.
John J. Coney #118
Location
Marshall P.D.



STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

2

PERMIT
TYPE II
JOHN J CONEY

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repair and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX DMT

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of section 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 4/30/2014

NUMBER 240196

EXPIRES 4/30/2016

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (6-10)

LAB-4 (R6-10)



STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.



Operator **CONEY, JOHN**
Permit No **240196**
Date Issued **4/30/2014** Date Expires **4/30/2016**



GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number **15120** of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **May 4, 2015**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.1209%** (w/vol) ethyl alcohol. The expiration date for this lot number is **April 29, 2017** at 11:59 PM.

When used in a calibrated Simulator, operating at $34^{\circ}\text{C} \pm .2^{\circ}\text{C}$, this solution will give a breath alcohol analysis instrument reading of **0.100 g/210L \pm 3%**.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN08051301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



Missouri Department of Health and Senior Services
 P.O. Box 570, Jefferson City, MO 65102-0570 Phone: 573-751-6400 FAX: 573-751-6010
 RELAY MISSOURI for Hearing and Speech Impaired 1-800-735-2966 VOICE 1-800-735-2466
Gail Vasterling
 Director



Jeremiah W. (Jay) Nixon
 Governor

Missouri Department of Health and Senior Services Breath Alcohol Program

SIMULATOR CALIBRATION REPORT

This is to certify that the simulator listed below has been examined and tested using standards traceable to the National Institute of Standards and Technology (NIST) in accordance to the standards set by the Rules of Missouri Department of Health and Senior Services, 19 CSR 25-30.

SIMULATOR INFORMATION

Agency: MARSHALL PD
Serial Number: SD2277
Manufacturer: Guth
Model Number: 10-4D

CALIBRATION RESULTS

<u>Reference Temperature</u>	<u>Simulator Temperature</u>
33.98	34.0

This calibration was performed with NIST-Traceable Thermometer SN: 094948

This simulator was tested by: DRL

This testing was performed: 10/07/2015

This certification expires: 10/07/2016

Signature of certifying DHSS Scientist: 

Name of certifying DHSS Scientist: Ellen Strawsine