

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY BREATH ALCOHOL PROGRAM

INTOX DMT MAINTENANCE REPORT

REPORT #1

Complete this report at the time of the regular m Complete this report whenever the instrument is Retain the original and send a copy within 15 da	serviced or repaired and	whenever it is placed	IVED Ol Day at 9:51	am, Jul 08, 2016	
INTOX DMT SN NAME OF AGENCY Stone Coun	ty Sheriff's Office		DATE OF INSPECTION 07/06/2016		
LOCATION OF INSTRUMENT (STREET AND CITY) 110 S Maple, Galena, MO		-	TIME OF INSPECTION 15:32:00		
CHECKLIST: Place a mark in the box by each values where determined). Unmarked items mu	item if found to be satisfa st be corrected before us	ctory or is operating wi	thin established limits.	(Write in observed	
☑ DIAGNOSTIC RECORD				<u></u>	
DATE AND TIME 07/06/2016 15:32:02					
☑ PROGRAM ☑ FILTER 1					
☑ SAMPLE CHAMBER 48.8°C		☑ FILTER 2			
☑ BREATH TUBE 44.0°C ☑ FILTER 3					
X PUMP	☑ PUMP ☑ INTERNAL STANDARD				
BREATH ANALYZER ACCURACY STANDA	RDS				
☑ SIMULATOR STANDARD ☐ COMPRESSED ETHANOL-GAS MIXTURE					
☑ STANDARD SUPPLIER GUTH	LOT#_	15120	EXP. DATE_	04/29/2017	
☑ SIMULATOR TEMP (34°C ± 0.2°C) 34.0	SIMULA	TOR SN <u>SD2282</u>	SIMULATOR EXP D	ATE 12/07/2016	
 □ CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT) Run three tests using a standard. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard being used. □ 0.10% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE □ 0.08% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE □ 0.04% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE 					
TEST 1: 0.097	TEST 2: 0.097		TEST 3: 0.097	····	
☑ PERFORM R.F.I. TEST					
INDICATE THE NUMBER OF BREATH TES	TS IN THE FOLLOWIN	G RANGES SINCE T	HE LAST MAINTEN	ANCE REPORT:	
REFUSALS: 0 004: 2	.0509: 1	.1014: 0	.1519: 1	OVER .19: 0	
LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR MO ESTABLISHED LIMITS (USE OTHER SIDE IF NECESSARY)	DDIFICATION THAT WAS MADE TO	RESTORE THE INSTRUMENT T	TO OPERATE SATISFACTORILY	AND WITHIN	
INSPECTING OFFICER				,	
SIGNATURE PRINT FULL NAME DANIEL FLETCHER					
TYPE II PERMIT NUMBER 240406	EXPIRATION DATE 11/20/2016	TELEPHONE NI 417-357			
RETURN COMPLETED REPORT TO THE Breath Alcohol Program, MO Department of Health and Senior Services Southeast District Office 2875 James Blvd, Poplar Bluff, MO 63901					



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

PERMIT



DANIEL D FLETCHE

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX DMT of the alcoholic content of blood from a sample of expired air. Permit issued under the part of the

on of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections		
nit issued under the		
le of expired air. Pen	SMo.	
blood from a sampl	through 306, 119 R	
alcoholic content of	RSMo and 306,111	
or the determination of the	577,020 through 577,041, RSMo and 306,111 through 306,119 RSMo.	
or Th	577.0	

DATE 11/20/2014

NUMBER 240406

EXPIRES 11/20/2016

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

GLO Dustant

LAB-4 (PB-1

MO 580-1771 (6-10)



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 15120 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on May 4, 2015, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1209% (w/vol) ethyl alcohol. The expiration date for this lot number is April 29, 2017 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN08051301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.