



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES  
 STATE PUBLIC HEALTH LABORATORY  
**ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT**

**RECEIVED**

By Tracy Crews at 3:15 pm, Dec 11, 2023

**ORIGINAL**

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 087965	NAME OF AGENCY Cass County Sheriff's Office	DATE OF INSPECTION 12/11/2024
LOCATION OF INSTRUMENT (STREET AND CITY) 2501 W. Mechanic, Harrisonville		TIME OF INSPECTION 0900

**CHECKLIST:** Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

**BREATH ALCOHOL ACCURACY STANDARDS**

- SIMULATOR SOLUTION
- COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER Intoximeters LOT # AG305102 EXP. DATE 02/20/2025

SIMULATOR TEMPERATURE (34°C ± 0.2°C) SIM. SN SIM. NIST EXP DATE

- CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)  
 Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)
  - 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
  - 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
  - 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 • .102	TEST 2 • .103	TEST 3 • .104
---------------	---------------	---------------

- RFI DETECTOR OPERATING

**INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)**

REFUSALS	(0-.04)	(.05-.09)	(.10-.14)	(.15-.19)	(OVER .19)
----------	---------	-----------	-----------	-----------	------------

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

<b>INSPECTING OFFICER</b>	
SIGNATURE 	PRINT NAME Det. Cpl. James N. Rew #563
TYPE II PERMIT NUMBER/EXPIRATION DATE 220231 09/09/2024	TELEPHONE NUMBER (816) 380-5200

**Return completed report to the:** Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.

AS IV Serial no: 087965  
Version no: 532B

TEST RECORD 00726

Temp Date Time 21OL<sup>9/</sup>

Air Blank:  
12/11/23 09:04 .000  
Calibration Check:  
19 12/11/23 09:04 .102

Subject Name  
*Test 7*  
Subject I.D.

Operator Name, I.D.  
*Rew 567 220231 9/9/24*  
Location  
*2501 W. Medline*

AS IV Serial no: 087965  
Version no: 532B

TEST RECORD 00727

Temp Date Time 21OL<sup>9/</sup>

Air Blank:  
12/11/23 09:07 .000  
Calibration Check:  
19 12/11/23 09:07 .103

Subject Name  
*Test 2*  
Subject I.D.

Operator Name, I.D.  
*Rew 567 220231 9/9/24*  
Location  
*2501 W. Medline*

AS IV Serial no: 087965  
Version no: 532B

TEST RECORD 00728

Temp Date Time 21OL<sup>9/</sup>

Air Blank:  
12/11/23 09:09 .000  
Calibration Check:  
20 12/11/23 09:09 .104

Subject Name  
*Test 3*  
Subject I.D.

Operator Name, I.D.  
*Rew 567 220231 9/9/24*  
Location  
*2501 W. Medline*

AS IV Serial no: 087965  
Version no: 532B

TEST RECORD 00729

Temp Date Time 21OL<sup>9/</sup>

VOID: RFI  
12 12/11/23 09:10

Subject Name  
*Test RFI*  
Subject I.D.

Operator Name, I.D.  
*Rew 567 220231 9/9/24*  
Location  
*2501 W. Medline*

AS IV Serial no: 087965  
Version no: 532B

TEST RECORD 00730

Temp Date Time 21OL<sup>9/</sup>

Air Blank:  
12/11/23 09:12 .000  
Subject Test: Auto  
21 12/11/23 09:12 .000

Subject Name  
*Test Blank*  
Subject I.D.

Operator Name, I.D.  
*Rew 567 220231 9/9/24*  
Location  
*2501 W. Medline*



Airgas USA LLC (LAB)  
 3500 Bernard Street  
 St. Louis, Mo. 63103  
 Ph: (314) 533-3100  
 Fax: (314) 533-7328

## Certificate of Analysis

**Customer Name**  
 Exclusive Supplier  
 Intoximeters, Inc.  
 2081 Craig Road  
 St. Louis, Mo 63146

**Test Date:** 20-Feb-2023

**Lot #** AG305102 **Model** 108

<b>Exp Date</b> 20-Feb-2025	<b>Cyl. Type</b> 108	<b>Component</b> Ethanol Nitrogen	<b>Certified Concentration</b> 0.100 ± 2% BrAC (272 ppm)
--------------------------------	-------------------------	---	---

**Certification Traceable to N.I.S.T. RGM and to CRM Ethanol Standards:**

RGM Serial No.	Concentration	RGM Serial No.	Concentration
EB0010581	391.8 ppm	EB0010603	392.5 ppm
EB0010570	259.8 ppm	EB0010559	258.9 ppm
EB0010285	209.0 ppm	EB0010562	104.2 ppm
EB0010561	103.7 ppm	EB0010579	52.94 ppm
EB0010681	52.22 ppm		

CRM Serial No.	Concentration	CRM Serial No.	Concentration
CC727481	800.0 ppm	CC727493	390.0 ppm
CC727496	253.0 ppm	CC727498	150.0 ppm

**Analytical Method:** NDIR

Digitally signed by:Quality Control  
 Reason:Dry gas standard certification of analysis  
 Location:Airgas USA LLC (Lab)  
 Date:02.20.2023 17:37

Approved for Release:   
 Rod Marsala

ISO 17025:2017 A2LA accredited. Certificate Number 3082.06  
 ISO 17034:2016 A2LA accredited. Certificate Number 3082.07



STATE OF MISSOURI  
 DEPARTMENT OF HEALTH AND SENIOR SERVICES  
 BREATH ALCOHOL PROGRAM



**PERMIT**  
**TYPE II**  
**JAMES N. REW**

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

**ALCO-SENSOR IV WITH PRINTER, INTOX EC/IR II**

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 9/9/2022

NUMBER 220231

EXPIRES 9/9/2024

*Laura Q. Way*

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

*Donald A. Kamm*

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES