





MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

		3915-000 Persanytina					
Complete this report in duplicate at the time Send copy to Department of Health and Sen			, and whene	ver instrument is repaired.			
ALCO SENSOR IV SN 107981	NAME OF AGENCY MSHP		DATE OF 07/28/	INSPEČTION 2023			
LOCATION OF INSTRUMENT (STREET AND CITY) 891 TECHNOLOGY DRIVE, WELDON	NT)	TIME OF 2:11 p	INSPECTION M				
CHECKLIST: Place a mark in the box by each	h item if found to be satisfactory or if	operating within esta	100 - 100 -				
where determined.) Unmarked items must be	e corrected before using instrument						
DIGITAL READOUT (ALL ELEMENTS C)PERATIONAL)						
✓ TEMPERATURE OF ALCO SENSOR (1)	0°C - 40°C)						
✓ PRINTER WORKING PROPERLY							
☑ TIME AND DATE DISPLAYING PROPE	RLÝ						
BREATH ALCOHOL ACCURACY STANDA	RDS			540			
☑ SIMULATOR SOLUTION	□ com	PRESSED ETHANO	L-GAS MIXT	TURE			
✓ STANDARD SUPPLIER GUTH LABO	RATORIES, INC. LOT # 2318	0 EXP. [OATE 05/17/	2025			
☑ SIMULATOR TEMPERATURE (34°C ±	SIMULATOR TEMPERATURE (34°C ± 0.2°C)34.00 SIM. SN MP2459 SIM. NIST EXP DATE01/27/2024						
less. Check the box corresponding to the ✓ 0.100% STANDARD - MUST READ O.080% STANDARD - MUST READ 0.040% STANDARD - MUST READ	D BETWEEN 0.095% and 0.105% IF D BETWEEN 0.076% and 0.084% IF D BETWEEN 0.038% and 0.042% IF	NCLUSIVE NCLUSIVE NCLUSIVE					
TEST 1 .102	TEST 2 ▼ .102	TEST 3	TEST 3 • .101				
☑ RFI DETECTOR OPERATING							
INDICATE THE NUMBER OF BREATH TES (DO NOT INCLUDE SELF-ADMINISTERED		S SINCE THE LAST	MAINTENAI	NCE REPORT:			
REFUSALS 0 (004) 0	(.0509) 0 (.1014)	0 (.1519	0	(OVER .19) 0			
List any new parts and describe any alterat established limits (use other side if necessar		o restore the instrun	nent to opera	te satisfactorily and within			
INSPECTING OFFICER				10			
SIGNATURE		A. MICH	ELS				
TYPE II PERMIT NUMBER EXPIRATION DATE PERMIT NUMBER 210321, EXPIRES	[2] [2]	TELEPHONE NUMBER (636) 300-2800					
Return completed report to the: Breath A		Health and Senior S	Services, Sou	utheast District Office			

Version no: 532B

TEST RECORD 00352
9/
Temp Bate Time 210L

Air Blank: 07/28/23 14:11 .000

Calibration Check: 23 07/28/23 14:11 .102

Subject Name
Main

Subject I.B.

Operator Name, I.B.

A. Michels # 21032/
Location

Troop C HQ

AS IV Serial no: 107981

AS IV Serial no: 107981
Version no: 532B

TEST RECORD 00353

Jemp Bate Time 210L

Air Blank:
07/28/23 14:14 .000
Calibration Check:
23 07/28/23 14:14 .102

Subject Name
Muin

Subject I.D.

Operator Name, I.D.

A.M.c.lek #210321
Location

Troop C HQ

AS IV Serial no: 107981
Version no: 532B

TEST RECORD 00354

Temp Date Time 210L

Air Blank: 07/28/23 14:16 .000
Calibration Check: 24 07/28/23 14:16 .101

Subject Name

Majn +

Subject I.D.

Operator Name, I.D.

A Michel #210321
Location

Troop (H Q

187981	불	8	210L			1	7	
no: 10 532B	- REPRINT	D 66355	Time	14:24			e, I.B.	3
~		TEST RECORD	Date	D: RFI 07/28/23 14:24	Main L	t I.D.	Nam	CH.
AS IV Seria Version no:	TEST RECORD	TES	Temp	UOID: 1	Subject	Subject	Operator A. Mic.	Tog



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 23180 of
Alcohol Reference Solution for Simulator were analyzed by
gas chromatography on May 18, 2023, using a Perkin Elmer Gas Chromatograph
Autosystem XL S/N: 610N9030209, and found to contain 0.1220% (w/vol)
ethyl alcohol. The expiration date for this lot
number is May 17, 2025 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN11172002 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT TYPE II

ADAM J. MICHELS

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE	12/16/2021	Laura a Nay			
		DIRECTOR OF STATE PUBLIC HEALTH LABORATORY			
NUMBER	210321	Daniel S. Kann w			
EXPIRES	12/16/2023				
		DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES			

MO 580-0771 (6-10)

LAB-4 (R6-10)



The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired ali in Missouri.

Operator MICHELS, ADAM Permit No 210321

