



ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED

By Tracy Crews at 10:37 am, Aug 03, 2023

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 107989	NAME OF AGENCY FLORISSANT POLICE DEPARTMENT	DATE OF INSPECTION 08/01/2023
LOCATION OF INSTRUMENT (STREET AND CITY) 1700 US HWY 67		TIME OF INSPECTION 10:02 am

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

- SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE
- STANDARD SUPPLIER INTOXIMETERS LOT # AG304601 EXP. DATE 02/15/2025
- SIMULATOR TEMPERATURE (34°C ± 0.2°C) SIM. SN SIM. NIST EXP DATE

- CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)
 - 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
 - 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
 - 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 → .101	TEST 2 → .102	TEST 3 → .102
---------------	---------------	---------------

- RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	(0-.04)	(.05-.09)	(.10-.14)	(.15-.19)	(OVER .19)
----------	---------	-----------	-----------	-----------	------------

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

Instrument functioning withing DHSS guidelines

INSPECTING OFFICER

SIGNATURE ▶ 	PRINT NAME Kyle Feldmann
TYPE II PERMIT NUMBER/EXPIRATION DATE 220242 10/05/2024	TELEPHONE NUMBER (314) 831-7000

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.

AS IV Serial no: 107989
Version no: 532B

TEST RECORD 01364

Temp Date Time ^{s/} 210L

Air Blank:
08/01/23 10:02 .000
Calibration Check:
21 08/01/23 10:02 .101

Subject Name

TEST 1

Subject I.D.

Operator Name, I.D.

FEDMANN 220242

Location

FPD

AS IV Serial no: 107989
Version no: 532B

TEST RECORD 01365

Temp Date Time ^{s/} 210L

Air Blank:
08/01/23 10:04 .000
Calibration Check:
21 08/01/23 10:04 .102

Subject Name

TEST 2

Subject I.D.

Operator Name, I.D.

FEDMANN 220242

Location

FPD

AS IV Serial no: 107989
Version no: 532B

TEST RECORD 01366

Temp Date Time ^{s/} 210L

Air Blank:
08/01/23 10:07 .000
Calibration Check:
21 08/01/23 10:07 .102

Subject Name

TEST 3

Subject I.D.

Operator Name, I.D.

FEDMANN 220242

Location

FPD

AS IV Serial no: 107989
Version no: 532B

TEST RECORD 01367

Temp Date Time ^{s/} 210L

VOID: RFI
12 08/01/23 10:08

Subject Name

RFI

Subject I.D.

Operator Name, I.D.

FEDMANN 220242

Location

FPD

AS IV Serial no: 107989
Version no: 532B

TEST RECORD 01368

Temp Date Time ^{s/} 210L

Air Blank:
08/01/23 10:09 .000
Subject Test: Auto
22 08/01/23 10:09 .000

Subject Name

BLANK

Subject I.D.

Operator Name, I.D.

FEDMANN 220242

Location

FEDMANN FPD



Airgas USA LLC (LAB)
 3500 Bernard Street
 St. Louis, Mo. 63103
 Ph: (314) 533-3100
 Fax: (314) 533-7328

Certificate of Analysis

Customer Name
 Exclusive Supplier
 Intoximeters, Inc.
 2081 Craig Road
 St. Louis, Mo 63146

Test Date: 15-Feb-2023

Lot # AG304601 **Model** 108

Exp Date 15-Feb-2025	Cyl. Type 108	Component Ethanol Nitrogen	Certified Concentration 0.100 ± 2% BrAC (272 ppm)
--------------------------------	-------------------------	---	---

Certification Traceable to N.I.S.T. RGM and to CRM Ethanol Standards:

RGM Serial No.	Concentration	RGM Serial No.	Concentration
EB0010581	391.8 ppm	EB0010603	392.5 ppm
EB0010570	259.8 ppm	EB0010559	258.9 ppm
EB0010285	209.0 ppm	EB0010562	104.2 ppm
EB0010561	103.7 ppm	EB0010579	52.94 ppm
EB0010681	52.22 ppm		

CRM Serial No.	Concentration	CRM Serial No.	Concentration
CC727481	800.0 ppm	CC727493	390.0 ppm
CC727496	253.0 ppm	CC727498	150.0 ppm

Analytical Method: NDIR

Digitally signed by:Quality Control
 Reason:Dry gas standard certification of analysis
 Location:Airgas USA LLC (Lab)
 Date:02.16.2023 13:50

Approved for Release: 
 Rod Marsala

ISO 17025:2017 A2LA accredited. Certificate Number 3082.06
ISO 17034:2016 A2LA accredited. Certificate Number 3082.07



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

2

PERMIT
TYPE II
KYLE J. FELDMANN

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX EC/IR II

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 10/5/2022

NUMBER 220242

EXPIRES 10/5/2024

Mike Mason

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

David J. Nielson

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (6-10)

LAB-4 (R6-10)

 **STATE OF MISSOURI**
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator FELDMANN, KYLE
Permit No 220242
Date Issued 10/5/2022 **Date Expires** 10/5/2024

