

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the tin Send copy to Department of Health and Se	ne of the regular month	ly preventative mainter	nance check, and	d whenever instrument is repaired	
ALCO SENSOR IV SN 111327	of Health and Senior Services; retain original in department file. NAME OF AGENCY Lawon Police Dept			DATE OF INSPECTION	
LOCATION OF INSTRUMENT (STREET AND CITY) 103 W 3rd ST, Lawson, MO 64062	Lawori Police L	Эер т		03/08/2023 TIME OF INSPECTION DOF	
CHECKLIST: Place a mark in the box by ea	ch item if found to be sa	tisfactory or if operating	I within establish	5:00 pm /730 FROM St	
		ng instrument.	·		
DIGITAL READOUT (ALL ELEMENTS	OPERATIONAL)				
TEMPERATURE OF ALCO SENSOR (10°C - 40°C)			RECEIN	RECEIVED	
PRINTER WORKING PROPERLY			By Tracy	By Tracy Crews at 3:10 pm, Mar 10, 2023	
☑ TIME AND DATE DISPLAYING PROPERLY					
BREATH ALCOHOL ACCURACY STANDA					
☑ SIMULATOR SOLUTION ☐ COMPRESSED ETHANOL-GAS MIXTURE					
CTANDADD CUIDOUTE Cuth Labo					
		LOT # 22080	EXP. DATE	03/07/2024	
SIMULATOR TEMPERATURE (34°C ±	0.2°C) <u>34.0</u> S	IM. SNDR5392	2 SIM. NI	IST EXP DATE <u>07/07/2023</u>	
0.100% STANDARD - MUST REAL 0.080% STANDARD - MUST REAL 0.040% STANDARD - MUST REAL) BETWEEN 0.076% ar) BETWEEN 0.038% ar	nd 0.084% INCLUSIVE			
TEST 1 • .095	TEST 2 .096		TEST 3 🖛 .096	ST 3 • .096	
RFI DETECTOR OPERATING	2				
INDICATE THE NUMBER OF BREATH TES (DO NOT INCLUDE SELF-ADMINISTERED	TS IN THE FOLLOWIN	NG RANGES SINCE T	HE LAST MAIN	TENANCE REPORT:	
REFUSALS (004) 1	(.0509)	(.1014)	(.1519)	(OVER .19)	
List any new parts and describe any alteratiestablished limits (use other side if necessar Adjusted time by two minutes (slow)	on or modification that y).	was made to restore the	ne instrument to	operate satisfactorily and within	
INSPECTING OFFICER					
SIGNATURE		1	RINT NAME Shawn Fields		
TYPE II PERMIT NUMBER/EXPIRATION DATE 220274 12/21/2024		1	ELEPHONE NUMBER (816) 580-7210		
Return completed report to the: Breath Alby mail, fa	cohol Program, MO Depax, or email.	partment of Health and	Senior Services	s, Southeast District Office	

AS IV Serial no: 111327 Version no: 532B TEST RECORD 00806 Date Time 210L Air Blank: 03/08/23 17:34 .000 Calibration Check: 24 03/08/23 17:34 .095 Subject Name Subject I.D. Operator Name, I.D. Location Lausen AS IV Serial no: 111327 Version no: 532B TEST RECORD 00809 Date Time 210L VOID: RFI 12 03/08/23 17:39 Subject Name

AS IV Serial no: 111327 Version no: 532B TEST RECORD 00807 9/ Temp Date Time 210L Air Blank: 03/08/23 17:36 .000 Calibration Check: 24 03/08/23 17:36 .096 Subject Name 1051 Subject I.D. Operator Name, I.D.

Location

inxin

AS IV Serial no: 111327
Version no: 532B

TEST RECORD 00808

Temp Date Time 210L

Air Blank:
03/08/23 17:37 .000
Calibration Check:
25 03/08/23 17:37 .096

Subject Name

Test

Subject I.D.

Operator Name, I.D.

Fields, Shaw July
Location

Larson PD

Subject Name

Test

Subject I.B.

RFI

Operator Name, I.D.

Larson PD



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 22080 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on March 9, 2022, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1214% (w/vol) ethyl alcohol. The expiration date for this lot number is March 7, 2024 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley. President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03052002 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



MO 580-0771 (6-10)

STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT TYPE II

SHAWN FIELDS

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

NUMBER 220274

EXPIRES 12/21/2024

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

Daves I. nichelson

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

LAB-4 (R6-10)



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in bre "the form of expired air in Missouri.

Operator FIELDS, SHAWN

ate Issued 12/21/2022

Date Expires 12/21/2024

