



**ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT**

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 119733	NAME OF AGENCY Hollister PD	DATE OF INSPECTION 02/19/2024
LOCATION OF INSTRUMENT (STREET AND CITY) 240 Hollister Pointe Dr, Hollister, MO 65672		TIME OF INSPECTION 0:14 am

**CHECKLIST:** Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

**BREATH ALCOHOL ACCURACY STANDARDS**

- SIMULATOR SOLUTION  COMPRESSED ETHANOL-GAS MIXTURE
- STANDARD SUPPLIER Guth Labs LOT # 23180 EXP. DATE 05/17/2025
- SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIM. SN SD2732 SIM. NIST EXP DATE 03/21/2024
- CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)  
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)
  - 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
  - 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
  - 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1  .100	TEST 2  .100	TEST 3  .100
--------------	--------------	--------------

- RFI DETECTOR OPERATING

**INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)**

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	2	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

**INSPECTING OFFICER**

SIGNATURE 	PRINT NAME David Brinegar
TYPE II PERMIT NUMBER/EXPIRATION DATE 230042 Exp. 03/27/2025	TELEPHONE NUMBER (417) 334-3000

**Return completed report to the:** Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.