



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED

By Tracy Crews at 2:12 pm, Nov 05, 2020

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 035714	PRINTER SN 092.3576.249	DATE OF INSPECTION 10/31/2020
LOCATION OF INSTRUMENT (STREET AND CITY) 203 Veterans Memorial Parkway, Wright City, Missouri, 63390		TIME OF INSPECTION 5:22 am

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

- SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER Guth Laboratories LOT # 20190 EXP. DATE 04/06/2022

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0C SIMULATOR SN SD2745 SIMULATOR EXP DATE 04/28/2021

- CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
 Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)
 - 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
 - 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
 - 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 .102 TEST 2 .103 TEST 3 .103

- RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	1	(0-.04)	0	(.05-.09)	0	(.10-.14)	1	(.15-.19)	4	(OVER .19)	2
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

INSPECTING OFFICER

SIGNATURE 	PRINT NAME M. Lackey
TYPE II PERMIT NUMBER/EXPIRATION DATE 200109 03/02/2022	TELEPHONE NUMBER (636) 745-3541

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Boulevard
 Poplar Bluff, MO 63901

AS IV Serial no: 685714
Version no: 532B

TEST RECORD 01147

Temp Date Time 210L
VOID: VPI
12 10/31/20 05:29

Subject Name
Blank Test
Subject I.D.
Lackey 114
Operator Name, I.D.
Lackey
Location
203 VMP
Wright City, MO 63390

AS IV Serial no: 685714
Version no: 532B

TEST RECORD 01145

Temp Date Time 210L
VOID: VPI
12 10/31/20 05:27

Subject Name
Blank Test
Subject I.D.
114
Operator Name, I.D.
Lackey
Location
203 VMP
Wright City, MO 63390

AS IV Serial no: 685714
Version no: 532B

TEST RECORD 01145

Temp Date Time 210L
Air Blank
10/31/20 05:24 .000
Calibration Check:
21 10/31/20 05:24 .103

Subject Name
Blank Test
Subject I.D.
114
Operator Name, I.D.
Lackey
Location
203 VMP
Wright City, MO 63390

AS IV Serial no: 685714
Version no: 532B

TEST RECORD 01144

Temp Date Time 210L
Air Blank
10/31/20 05:22 .000
Calibration Check:
21 10/31/20 05:22 .102

Subject Name
Blank Test
Subject I.D.
114
Operator Name, I.D.
Lackey
Location
203 VMP
Wright City, MO 63390



GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 20190 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on April 8, 2020, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1206% (w/vol) ethyl alcohol. The expiration date for this lot number is April 6, 2022 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN02271802 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

2

**PERMIT
 TYPE II**

MATT LACKEY

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 3/2/2020

NUMBER 200109

EXPIRES 3/2/2022

MO 580-0771 (6-10)

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

LAB-4 (F6-10)

STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator LACKEY, MATT
 Permit No 200109
 Date Issued 3/2/2020 Date Expires 3/2/2022