



### MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

#### ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

AVESCE .									
Complete this report in duplicate at the tir Send copy to Department of Health and S						nd whene	ver instrument is	repaired.	
DECO SENSOR IV SN PRINTER SN 096.3580.957						DATE OF INSPECTION 03/06/2020			
LOCATION OF INSTRUMENT (STREET AND CITY) 5434 S. Tower Drive, Battlefield, MO 65619						TIME OF INSPECTION 8:17 pm			
CHECKLIST: Place a mark in the box by	each item if found				ing within estab			erved val-	
ues where determined.) Unmarked items i	must be corrected	before L	ising instrume	ent.		No. 1950 v. 1 - 1			
DIGITAL READOUT (ALL ELEMENTS	S OPERATIONAL)								
✓ TEMPERATURE OF ALCO SENSOR	(10°C - 40°C)								
PRINTER WORKING PROPERLY									
☑ TIME AND DATE DISPLAYING PROF	PERLY								
BREATH ALCOHOL ACCURACY STAND	DARDS								
SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE									
STANDARD SUPPLIER Guth Laboratories LOT # 19160 EXP.						E 07/09/2	2021		
SIMULATOR TEMPERATURE (34°C ± 0.2°C)34 SIMULATOR SNSD2251 SIMULATOR EXP DATE _09/18/2020									
CALIBRATION CHECK – (ONLY ONE Run three tests using a standard solutiless. Check the box corresponding to to 0.100% STANDARD - MUST RE. 0.080% STANDARD - MUST RE. 0.040% STANDARD - MUST RE.	tion. All three tests the standard soluti AD BETWEEN 0.0 AD BETWEEN 0.0	s must b on being 195% and 176% and	e within ±5% g used. (PRIN d 0.105% INC d 0.084% INC	of the s TOUT A LUSIV LUSIV	standard value ATTACHED) E E		t have a spread	of .005 or	
TEST 1 <b>▼</b> .101	TEST 2 🖛 .10	ST 2 🕶 .102			TEST 3   .102				
RFI DETECTOR OPERATING									
INDICATE THE NUMBER OF BREATH T (DO NOT INCLUDE SELF-ADMINISTERE		LLOWIN	G RANGES	SINCE	THE LAST MA	INTENAN	NCE REPORT:		
REFUSALS 0 (004) 0	(.0509)	0	(.1014)	1	(.1519)	0	(OVER .19)	0	
List any new parts and describe any alter established limits (use other side if necess		on that v	was made to	restore	the instrument	to opera	te satisfactorily a	and within	
INSPECTING OFFICER									
SIGNATURE AND					PRINT NAME Ronald M Payne				
TYPE II PERMIT NUMBER/EXPIRATION DATE 290164/08-01-2021					TELEPHONE NUMBER (417) 890-9876				
Return completed report to the: Breath	n Alcohol Program, James Boulevard	MO De	partment of H	ealth a	nd Senior Servi	ces, Sout	theast District Of	fice	

Poplar Bluff, MO 63901

AS IV Serial no: 097460 Version no: 5328

TEST RECORD 00863

Temp Date Time 210L

Air Blank: 83/86/20 20:17 .000 Subject Test: Auto 13 83/86/20 20:17 .000

Bubject Wame

Blank Test

Cegrator Hame, I.D.

A. Payne / 290164

Battlefield P.O.

AS IV Serial no: 097460 Version no: 532B

TEST RECORD 00865

9/ Tomp Date Time 210L

tir Blank! - 63/06/20 20:20 .000 Telibration Check: - 23 03/06/20 20:20 .101

wojeci Mame

ALL Check

Tubject I.D.

L. Payne/ 290164

Battlefield P. O.

ns IV Serial no: 097460 Version no: 5328

YEST RECORD 00867

mp Date Time 210L

17 Siens 83/86/28 20:24 .000 Slibration Check: 81 83/86/28 20:24 .192

Acc check

A. Payne 1290164
Battlefiel P.D.

AS IV Serial no: 097460 Jersion no: 532B

TEST RECORD 00864

Tomp Date Time 210L

VOID: RFI 12 03/06/20 20:18

Subject Name

RFI Test

A. Para 1290164

BAHlefield P.D.

AS IV Serial no: 097460 Version no: 532B

TEST RECORD 00866

Tamp Date Time 210L

tr Blånk! 03/06/20 20:22 .000 slibration Check! 3 03/06/20 20:22 .102

ALL Check

1. Parne/290164
Battlefield P.D.



# CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 19160 Alcohol Reference Solution for Simulator were analyzed by gas chromatography on July 10, 2019, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1202% (w/vol) ethyl alcohol. The expiration date for this lot number is July 9, 2021 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210 L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

> Ted L. Pauley, President GUTH LABORATORIES, INC.

Testing was conducted using Cerilliant Reference Standard lot number FN04271602 whose

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



#### STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



## PERMIT TYPE II

### RONALD M PAYNE

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repair and operate the following breath analyzer(s):

### ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sectio 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 8/1/2019

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

NUMBER 290164

EXPIRES 8/1/2021

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

LAB-4 (RS-4)

NIO 580-07-71 (5-10)



The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator PAYNE, RONALD

Permit No 290164

Date Issued 8/1/2019 Date Expires 8/1/2021

