



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED
 By Tracy Crews at 9:03 am, Feb 10, 2020

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 099360	PRINTER SN 0973584335	DATE OF INSPECTION 02/04/2020
LOCATION OF INSTRUMENT (STREET AND CITY) 540 Civic Blvd. Republic		TIME OF INSPECTION 11:20 pm

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

- SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER Guth Lab LOT # 18200 EXP. DATE 07/03/2020

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIMULATOR SN SD3326 SIMULATOR EXP DATE 02/08/2020

- CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
 Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)
 - 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
 - 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
 - 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 .100 TEST 2 .100 TEST 3 .100

- RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS 0 (0-.04) 0 (.05-.09) 0 (.10-.14) 0 (.15-.19) 0 (OVER .19) 0

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

INSPECTING OFFICER	
SIGNATURE 	PRINT NAME Frank Schreiber
TYPE II PERMIT NUMBER/EXPIRATION DATE 290110 05/21/2021	TELEPHONE NUMBER (417) 732-3900

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Boulevard
 Poplar Bluff, MO 63901

AS IV Serial no: 899368
Version no: 1321

TEST RECORD 89972

Temp Date Time 2:02

Air Blower
10/21/20 20:20 1.800
Cable 10/21/20 20:20 1.100
20 10/21/20 20:20 1.100

Subject Name

Subject ID:

Frank Schreiber

290110 5/21/2020

AS IV Serial no: 899368
Version no: 1321

TEST RECORD 89972

Temp Date Time 2:02

Air Blower
10/21/20 20:20 1.800
Cable 10/21/20 20:20 1.100
20 10/21/20 20:20 1.100

Subject Name

Frank Schreiber

290110 5/21/2021

AS IV Serial no: 899368
Version no: 1321

TEST RECORD 89972

Air Blower
10/21/20 20:20 1.800
Cable 10/21/20 20:20 1.100
20 10/21/20 20:20 1.100

Subject Name

Frank Schreiber

290110 5/21/2021

Frank Schreiber
290110 5/21/2020

AS IV Serial no: 899368
Version no: 1321
TEST RECORD 89972
Temp Date Time 2:02
Air Blower
10/21/20 20:20 1.800
Cable 10/21/20 20:20 1.100
20 10/21/20 20:20 1.100
Subject Name



GUTH LABORATORIES, INC.

880 NORTH 67th STREET • HARRISBURG, PA 17111-4811 • TELEPHONE: 717-684-8470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 18200 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on July 6, 2018, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1215% (w/vol) ethyl alcohol. The expiration date for this lot number is July 3, 2020 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN04271602 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

2

PERMIT
 TYPE II

FRANK G SCHREIBER

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repair and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX EC/IR II

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of section 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 5/21/2019

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

NUMBER 290110

EXPIRES 5/21/2021

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 680-0771 (6-10)

LAB-4 (R6-10)

STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator SCHREIBER, FRANK
 Permit No 290110
 Date Issued 5/21/2019 Date Expires 5/21/2021