



**ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT**

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 102466	PRINTER SN 079.3418.057	DATE OF INSPECTION 02-16-20
-----------------------------	----------------------------	--------------------------------

LOCATION OF INSTRUMENT (STREET AND CITY) 106 Progress Drive Sullivan, MO 63080	TIME OF INSPECTION 1420 hours
---	----------------------------------

**CHECKLIST:** Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

TEMPERATURE OF ALCO SENSOR (10°C - 40°C)

PRINTER WORKING PROPERLY

TIME AND DATE DISPLAYING PROPERLY

**BREATH ALCOHOL ACCURACY STANDARDS**

SIMULATOR SOLUTION  COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER Guth LOT # 19160 EXP. DATE 07-09-21

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIMULATOR SN SD3322 SIMULATOR EXP DATE 12-13-20

CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
- 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
- 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 ➡ .098

TEST 2 ➡ .100

TEST 3 ➡ .098

RFI DETECTOR OPERATING

**INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)**

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).  
Instrument operating within D.O.H. specifications.

**INSPECTING OFFICER**

SIGNATURE *Jason R. Stockton*

PRINT NAME  
Jason R. Stockton

TYPE II PERMIT NUMBER/EXPIRATION DATE  
290097 / 04-22-21

TELEPHONE NUMBER  
573 468-8001

**Return completed report to the:** Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office  
2875 James Boulevard  
Poplar Bluff, MO 63901

AS IV Serial no: 102466  
Version no: 532B

TEST RECORD 00873

Temp Date Time <sup>s/</sup> 210L

Air Blank:  
02/16/20 14:25 .000  
Calibration Check:  
20 02/16/20 14:25 .098

Subject Name

Subject I.D.

Operator Name, I.D.

Location

AS IV Serial no: 102466  
Version no: 532B

TEST RECORD 00874

Temp Date Time <sup>s/</sup> 210L

Air Blank:  
02/16/20 14:26 .000  
Calibration Check:  
22 02/16/20 14:26 .100

Subject Name

Subject I.D.

Operator Name, I.D.

Location

AS IV Serial no: 102466  
Version no: 532B

TEST RECORD 00875

Temp Date Time <sup>s/</sup> 210L

Air Blank:  
02/16/20 14:28 .000  
Calibration Check:  
23 02/16/20 14:28 .098

Subject Name

Subject I.D.

Operator Name, I.D.

Location

AS IV Serial no: 102466  
Version no: 532B

TEST RECORD 00876

Temp Date Time <sup>s/</sup> 210L

UOIT: RFI  
12 02/16/20 14:30

Subject Name

Subject I.D.

Operator Name, I.D.

Location



**GUTH LABORATORIES, INC.**

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

## CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 19160 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on July 10, 2019, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1202% (w/vol) ethyl alcohol. The expiration date for this lot number is July 9, 2021 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President  
GUTH LABORATORIES, INC.

***NIST Traceability:***

*Testing was conducted using Cerilliant Reference Standard lot number FN04271602 whose values are traceable to NIST.*

*All balances are calibrated annually by an outside agency using NIST traceable weights.*

*Calibration verification is done prior to each use utilizing NIST traceable weights.*



STATE OF MISSOURI  
 DEPARTMENT OF HEALTH AND SENIOR SERVICES  
 BREATH ALCOHOL PROGRAM

2

PERMIT  
 TYPE II

JASON R. STOCKTON

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 4/22/2019

NUMBER 290097

EXPIRES 4/22/2021

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (6-10)

LAB-4 (R6-10)



STATE OF MISSOURI  
 DEPARTMENT OF HEALTH AND SENIOR SERVICES  
 BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator STOCKTON, JASON  
 Permit No 290097  
 Date Issued 4/22/2019 Date Expires 4/22/2021

