

FAKED
2/29/20



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 107977	PRINTER SN 096.3580.877	DATE OF INSPECTION 02/29/2020
------------------------------------	-----------------------------------	---

LOCATION OF INSTRUMENT (STREET AND CITY) 301 S MAIN ST, EXCELSIOR SPRINGS, MO 64024	TIME OF INSPECTION 1:25 pm
---	--------------------------------------

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

- SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE
- STANDARD SUPPLIER GUTH LOT # 19160 EXP. DATE 07/09/2021
- SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIMULATOR SN MP3564 SIMULATOR EXP DATE 06/18/2020

- CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)
- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
- 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
- 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 ☛ .099	TEST 2 ☛ .099	TEST 3 ☛ .098
----------------------	----------------------	----------------------

- RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	1	(0-.04)	0	(.05-.09)	0	(.10-.14)	1	(.15-.19)	1	(OVER .19)	0
----------	----------	---------	----------	-----------	----------	-----------	----------	-----------	----------	------------	----------

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

INSPECTING OFFICER	
SIGNATURE <i>Sgt Brian K Kennedy</i>	PRINT NAME SGT BRIAN K KENNEDY
TYPE II PERMIT NUMBER/EXPIRATION DATE 290040 02/20/2021	TELEPHONE NUMBER (816) 630-2000

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
2875 James Boulevard
Poplar Bluff, MO 63901

AS IV Serial no: 107977
Version no: 532B

TEST RECORD 00871

Temp Date Time 210L
s/

VOID: RTJ

12 02/29/20 13:35

Subject Name

SIMULACOR
Subject I.D.

Operator Name, I.D.

KENNEDY 911

Location

301 S MAIN

EX SPAS, MO

AS IV Serial no: 107977
Version no: 532B

TEST RECORD 00870

Temp Date Time 210L
s/

Air Blank:

02/29/20 13:34 .000

Calibration Check:

23 02/29/20 13:34 .098

Subject Name

SIMULACOR
Subject I.D.

Operator Name, I.D.

KENNEDY 911

Location

301 S MAIN

EX SPAS, MO

AS IV Serial no: 107977
Version no: 532B

TEST RECORD 00869

Temp Date Time 210L
s/

Air Blank:

02/29/20 13:32 .000

Calibration Check:

22 02/29/20 13:32 .099

Subject Name

SIMULACOR
Subject I.D.

Operator Name, I.D.

KENNEDY 911

Location

301 S MAIN

EX SPAS, MO

AS IV Serial no: 107977
Version no: 532B

TEST RECORD 00868

Temp Date Time 210L
s/

Air Blank:

02/29/20 13:30 .000

Calibration Check:

22 02/29/20 13:30 .099

Subject Name

SIMULACOR
Subject I.D.

Operator Name, I.D.

SCOTT KENNEDY 911

Location

301 S MAIN

EX SPAS, MO


Missouri Department of Health and Senior Services

 P.O. Box 570, Jefferson City, MO 65102-0570 Phone: 573-751-6400 FAX: 573-751-6010
 RELAY MISSOURI for Hearing and Speech Impaired 1-800-735-2966 VOICE 1-800-735-2466

Randall W. Williams, MD, FACOG
 Director

Michael L. Parson
 Governor

SIMULATOR CERTIFICATION REPORT

SIMULATOR INFORMATION

Simulator Serial Number: MP3564 **Manufacturer:** Guth
Model Number: 12V500
Agency: EXCELSIOR SPRINGS
Agency Address: 301 S MAIN, EXCELSIOR SPRINGS, MO 64024

NIST THERMOMETER INFORMATION

Serial Number: 17KMM00690 **Bias:** 0.00
Uncertainty: 0.02
Date of Certification: 1/31/2019 **Date of Expiration:** 1/31/2020

ENVIRONMENTAL CONDITIONS

The environmental conditions during testing are within the tolerances of DHSS BAP method 3.

VERIFICATION RESULTS

<u>Simulator Average</u>	<u>NIST Average</u>	<u>Combined Uncertainty</u>
33.99	34.00	.03

The combined uncertainty is calculated with a k=2 value.

ADJUSTMENT RESULTS

No adjustment was needed.

Date of testing: 6/17/2019
Certification Expiration: 6/17/2020
Simulator testing technician: S. GARY

Notes on Condition: none

Deviation(s) from method: none

DHSS BAP Scientist Approving: B. LUTMER
Certification No: MP3564_6172019

X *Brian Lutmer*

DHSS BAP Scientist Approving

**GUTH LABORATORIES, INC.**

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number **19160** of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **July 10, 2019**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.1202%** (w/vol) ethyl alcohol. The expiration date for this lot number is **July 9, 2021** at 11:59 PM.

When used in a calibrated Simulator, operating at $34^{\circ}\text{C} \pm .2^{\circ}\text{C}$, this solution will give a breath alcohol analysis instrument reading of **0.100 g/210L \pm 3%**.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN04271602 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT
TYPE II

BRIAN K KENNEDY

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 2/20/2019

NUMBER 290040

EXPIRES 2/20/2021

MO 690-0771 (6-10)

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

LAB-4 (R6-10)

 **STATE OF MISSOURI**
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator KENNEDY, BRIAN
Permit No 290040
Date Issued 2/20/2019 Date Expires 2/20/2021

