



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED
 07/18/09
 Division of Public Health Services

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN <u>108268</u>	PRINTER SN <u>099.3586.791</u>	DATE OF INSPECTION <u>2/27/2020</u>
LOCATION OF INSTRUMENT (STREET AND CITY) <u>1781 Zumbel Rd. St. Charles</u>		TIME OF INSPECTION <u>4:20 pm</u>

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

TEMPERATURE OF ALCO SENSOR (10°C - 40°C)

PRINTER WORKING PROPERLY

TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

SIMULATOR SOLUTION COMPRESSED ETHANOL GAS MIXTURE

STANDARD SUPPLIER Guth Laboratories LOT # 19160 EXP. DATE 7/09/2021

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0°C SIMULATOR SN SD2248 SIMULATOR EXP DATE 5/22/2020

CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 • <u>.099</u>	TEST 2 • <u>.100</u>	TEST 3 • <u>.100</u>
----------------------	----------------------	----------------------

RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
 (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS <u>0</u>	(0-.04) <u>0</u>	(.05-.09) <u>0</u>	(.10-.14) <u>0</u>	(.15-.19) <u>0</u>	(OVER .19) <u>0</u>
-------------------	------------------	--------------------	--------------------	--------------------	---------------------

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

N/A

INSPECTING OFFICER

SIGNATURE <u>P.O. Kenneth E. Enz 397</u>	PRINT NAME <u>Ofc. Kenneth Enz 397</u>
TYPE II PERMIT NUMBER/EXPIRATION DATE <u>290116 5/29/2021</u>	TELEPHONE NUMBER <u>636-949-3300</u>

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
 2875 James Boulevard
 Poplar Bluff, MO 63901



GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 19160 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on July 10, 2019, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1202% (w/vol) ethyl alcohol. The expiration date for this lot number is July 9, 2021 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN04271602 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

2

PERMIT
TYPE II
KENNETH ENZ

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX EC/IR II

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 5/29/2019

NUMBER 290116

EXPIRES 5/29/2021

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri

Operator ENZ, KENNETH
Permit No 290116
Date Issued 5/29/2019 **Date Expires** 5/29/2021

AS 1U Serial no: 108268
Version no: 532B

TEST RECORD 00719

Temp Date Time 210L 9/

Air Blank: 02/27/20 16:20 .000
Calibration Check: 20 02/27/20 16:20 .099

Subject Name
Test 1
Subject I.D.

Operator Name, I.D.

En2 290114

Location

1781 Zumbeni Rd.

St. Charles

AS 1U Serial no: 108268
Version no: 532B

TEST RECORD 00720

Temp Date Time 210L 9/

Air Blank: 02/27/20 16:22 .000
Calibration Check: 21 02/27/20 16:22 .100

Subject Name
Test 2
Subject I.D.

Operator Name, I.D.

En2 290114

Location

1781 Zumbeni Rd.

St. Charles MO

AS 1U Serial no: 108268
Version no: 532B

TEST RECORD 00721

Temp Date Time 210L 9/

Air Blank: 02/27/20 16:24 .000
Calibration Check: 21 02/27/20 16:24 .100

Subject Name
Test 3
Subject I.D.

Operator Name, I.D.

En2 290114

Location

1781 Zumbeni Rd.

St. Charles MO

AS 1U Serial no: 108268
Version no: 532B

TEST RECORD 00722

Temp Date Time 210L 9/

VOID: RFI
12 02/27/20 16:25

Subject Name
RFI Check
Subject I.D.

Operator Name, I.D.

En2 290114

Location

1781 Zumbeni Rd.

St. Charles MO