



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 097419	NAME OF AGENCY Palmyra Police Department	DATE OF INSPECTION 11/01/2021
LOCATION OF INSTRUMENT (STREET AND CITY) 200 N. Main St. Palmyra		TIME OF INSPECTION 8:00 am

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

<input checked="" type="checkbox"/> SIMULATOR SOLUTION	<input type="checkbox"/> COMPRESSED ETHANOL-GAS MIXTURE
<input checked="" type="checkbox"/> STANDARD SUPPLIER <u>Guth Laboratories</u>	LOT # <u>21080</u> EXP. DATE <u>03/08/2023</u>
<input checked="" type="checkbox"/> SIMULATOR TEMPERATURE (34°C ± 0.2°C) <u>34.0</u>	SIM. SN <u>DR5308</u> SIM. NIST EXP DATE <u>07/12/2022</u>

CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
 Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
- 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
- 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 ← .099	TEST 2 ← .101	TEST 3 ← .101
---------------	---------------	---------------

RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0	(.0-.04)	0	(.05-.09)	0	(.10-.14)	1	(.15-.19)	0	(OVER .19)	0
----------	---	----------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

INSPECTING OFFICER	
SIGNATURE <i>Michael L. Baker</i>	PRINT NAME Michael L. Baker
TYPE II PERMIT NUMBER/EXPIRATION DATE 20251/09/24/2022	TELEPHONE NUMBER (573) 769-5540

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.

AS IV Serial no: 097419
Version no: 532B

TEST RECORD 00740

Temp	Date	Time	s/ 210L
------	------	------	------------

Air Blank:
11/01/21 08:50 .000
Calibration Check:
20 11/01/21 08:50 .099

Subject Name

Calibration Check

Subject I.D.

Michael BAKER

Operator Name, I.D.

Palmyra P.D

Location

AS IV Serial no: 097419
Version no: 532B

TEST RECORD 00741

Temp	Date	Time	s/ 210L
------	------	------	------------

Air Blank:
11/01/21 08:52 .000
Calibration Check:
20 11/01/21 08:52 .101

Subject Name

Calibration Check

Subject I.D.

Michael BAKER

Operator Name, I.D.

Palmyra P.D

Location

AS IV Serial no: 097419
Version no: 532B

TEST RECORD 00742

Temp	Date	Time	s/ 210L
------	------	------	------------

Air Blank:
11/01/21 08:55 .000
Calibration Check:
21 11/01/21 08:55 .101

Subject Name

Calibration Check

Subject I.D.

Michael BAKER

Operator Name, I.D.

Palmyra P.D

Location

AS IV Serial no: 097419
Version no: 532B

TEST RECORD 00743

Temp	Date	Time	s/ 210L
------	------	------	------------

VOID: RFI
12 11/01/21 08:05

Subject Name

Calibration/RFI Check

Subject I.D.

Michael BAKER

Operator Name, I.D.

Palmyra P.D

Location



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM



PERMIT
TYPE II

MICHAEL L. BAKER

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 9/24/2020

NUMBER 200251

EXPIRES 9/24/2022

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 589-0771 (6-10)

LAB-4 (R6-10)

 **STATE OF MISSOURI**
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator **BAKER, MICHAEL**
 Permit No **200251**
 Date Issued **9/24/2020** Date Expires **9/24/2022**





GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 21080 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on March 10, 2021, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1214% (w/vol) ethyl alcohol. The expiration date for this lot number is March 8, 2023 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03052002 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.