

**RECEIVED**

By Tracy Crews at 10:06 am, Aug 09, 2021

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES  
STATE PUBLIC HEALTH LABORATORY**ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT**

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 099360	NAME OF AGENCY Republic Police Department	DATE OF INSPECTION 08/07/2021
LOCATION OF INSTRUMENT (STREET AND CITY) 540 Civic Blvd., Republic MO		TIME OF INSPECTION 11:09 pm

**CHECKLIST:** Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument. DIGITAL READOUT (ALL ELEMENTS OPERATIONAL) TEMPERATURE OF ALCO SENSOR (10°C - 40°C) PRINTER WORKING PROPERLY TIME AND DATE DISPLAYING PROPERLY**BREATH ALCOHOL ACCURACY STANDARDS** SIMULATOR SOLUTION  COMPRESSED ETHANOL-GAS MIXTURE STANDARD SUPPLIER Guth Lab LOT # 19370 EXP. DATE 12/09/2021 SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0 SIM. SN SD3326 SIM. NIST EXP DATE 02/23/2022 CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 ← .100

TEST 2 ← .100

TEST 3 ← .099

 RFI DETECTOR OPERATING**INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:  
(DO NOT INCLUDE SELF-ADMINISTERED TESTS)**

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

**INSPECTING OFFICER**

SIGNATURE

PRINT NAME

Frank Schreiber

TYPE II PERMIT NUMBER/EXPIRATION DATE

210111 05/18/2023

TELEPHONE NUMBER

(417) 732-3900

**Return completed report to the:** Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.

AS IU Serial no: 099360  
Version no: 532B

TEST RECORD 01008

Temp Date Time 210L

UOIID: DPT  
12 08/07/21 23:53

Subject Name

Subject I.D.

Frank Schreiber

Operator Name, I.D.

21011 5/18/2023

Location

AS IU Serial no: 099360  
Version no: 532B

TEST RECORD 01007

Temp Date Time 210L

Air Blank:  
08/07/21 23:51 .000  
Calibration Check:  
25 08/07/21 23:51 .099

Subject Name

Subject I.D.

Frank Schreiber

Operator Name, I.D.

21011 5/18/2023

Location

AS IU Serial no: 099360  
Version no: 532B

TEST RECORD 01006

Temp Date Time 210L

Air Blank:  
08/07/21 23:50 .000  
Calibration Check:  
24 08/07/21 23:50 .100

Subject Name

Subject I.D.

Frank Schreiber

Operator Name, I.D.

21011 5/18/2023

Location

AS IU Serial no: 099360  
Version no: 532B

TEST RECORD 01005

Temp Date Time 210L

Air Blank:  
08/07/21 23:49 .000  
Calibration Check:  
24 08/07/21 23:49 .100

Subject Name

Subject I.D.

Frank Schreiber

Operator Name, I.D.

21011 5/18/2023

Location



## GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

### CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number **19370** of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **December 10, 2019**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.1199%** (w/vol) ethyl alcohol. The expiration date for this lot number is **December 9, 2021** at 11:59 PM.

When used in a calibrated Simulator, operating at  $34^{\circ}\text{C} \pm .2^{\circ}\text{C}$ , this solution will give a breath alcohol analysis instrument reading of **0.100 g/210L  $\pm$  3%**.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President  
GUTH LABORATORIES, INC.

*NIST Traceability:*

*Testing was conducted using Cerilliant Reference Standard lot number FN04271602 whose values are traceable to NIST.*

*All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.*



STATE OF MISSOURI  
 DEPARTMENT OF HEALTH AND SENIOR SERVICES  
 BREATH ALCOHOL PROGRAM

2

**PERMIT**  
**TYPE II**  
**FRANK G. SCHREIBER**

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

**ALCO-SENSOR IV WITH PRINTER, INTOX EC/IR II**

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 5/18/2021

NUMBER 210111

EXPIRES 5/18/2023

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (6-10)

LAB-4 (R6-10)

 STATE OF MISSOURI  
 DEPARTMENT OF HEALTH AND SENIOR SERVICES  
 BREATH ALCOHOL PROGRAM

**INSTRUMENT OPERATOR CARD**

*The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.*

Operator SCHREIBER, FRANK  
 Permit No 210111  
 Date Issued 5/18/2021 Date Expires 5/18/2023

