

# MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

#### ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time			
Send copy to Department of Health and Se	ne of the regular monthly preventative me enior Services; retain original in departme	aintenance check, and ent file.	whenever instrument is repaired.
alco sensor IV SN 105444 LOCATION OF INSTRUMENT (STREET AND CITY) 210 5 Clarke Ave (	NAME OF AGENCY City of Clever Poli	e Department	DATE OF INSPECTION  O(24) 2021  FIME OF INSPECTION  19:45
CHECKLIST: Place a mark in the box by ea where determined.) Unmarked items must	ach item if found to be satisfactory or if $openion$	erating within establishe	d limits. (Write in observed values
D DIGITAL READOUT (ALL ELEMENTS	OPERATIONAL)		
TEMPERATURE OF ALCO SENSOR	(10°C - 40°C)		responding to the second secon
A PRINTER WORKING PROPERLY	ente e en		M - Cut design into a little and dep projection of the project of
TIME AND DATE DISPLAYING PROP	PERLY		
BREATH ALCOHOL ACCURACY STAND.			
SIMULATOR SOLUTION	☐ COMPR	ESSED ETHANOL-GA	S MIXTURE
M STANDARD SUPPLIER GUTH L	aboratories LOT # 2168	EXP. DATE	03/08/2023
SIMULATOR TEMPERATURE (34°C ±	± 0.2°C) 34.0 °C sim. sn 5D	2Z59 sim. n	ST EXP DATE 05/11/2022
O.040% STANDARD - MUST REA	AD BETWEEN 0.076% and 0.084% INCL AD BETWEEN 0.038% and 0.042% INCL	USIVE	
TEST 1 - 0.097	TEST 2 0.097	TEST 3	0.098
RFI DETECTOR OPERATING			
INDICATE THE NUMBER OF BREATH TE (DO NOT INCLUDE SELF-ADMINISTERE	ESTS IN THE FOLLOWING RANGES SI D TESTS)	NCE THE LAST MAIN	TENANCE REPORT:
REFUSALS (004)	(.0509) (.1014)	(.1519) Q	(OVER .19)
List any new parts and describe any altera established limits (use other side if necessa	ation or modification that was made to re	estore the instrument to	operate satisfactorily and within
		and regulati	
Maintenance conducted	within 2) HSS TUCS	- Her	97 S,
Maintenance conducted	within DHSS Toles	vegora.	21 S.
Maintenance conducted	WITHIN AJHSS TORES	vegora.	21 S.
	WITHIN A) HSS TORES	vegoja.	21 S.
Maintenance conducted  INSPECTING OFFICER  SIGNATURE	WITHIN AJHSS TOTES	PRINT NAME	
INSPECTING OFFICER	within JJHSS Toles		Petersen

AS IV Serial no: 105444 AS IV Serial no: 105444 AS IV Serial no: 105444 Version not 5320 Version no: 5320 Version not 532B TEST RECORD 00755 TEST RECORD 00756 TEST RECORD 00757 Temp Date Temp Date Time 210L Temp Date Time 210L Air Blank: Air Blank: Air Blank: 86/24/21 19:52 .000 06/24/21 19:53 .000 06/24/21 19:55 .000 Calibration Check: Calibration Check: Calibration Check: 23 06/24/21 19:52 .097 24 06/24/21 19:53 .097 25 06/24/21 19:55 .098 Subject Name Subject Mane Subject Name Test 2 Test 1 Test 3 Subject I.D. Subject I.D. Subject I.N. Operator Name, I.D. Operator Name, I.D. Operator Name, I.D. 1) Petersen 210108 D Petersen Z10108 D Petersen 210108 Location Location Location 210 S Clarke Ave 210 5 Clarke Ave 210 5 Clorke Ave Clever MO 65631 Clever, Mo 65631 Clever, Mo 65631

AS IV Serial no: 185444
Version no: 5321: AS IV Version
TEST RECORD 60758
Temp Date Time 2101.

VOID: RFI
12 86/24/21 19:56 Air B1.

Subject Name Calibrity
26 86/2
Subject I.D.

Decrator Name: I.D.

Clever Mo 65631

Clever Mo 65631

AS IV Serial no: 105444
Version no: 5328

TEST RECORD 00759

Temp Date Time 2101

Air Blank:
 06/24/21 19:57 .000

Calibration Check:
 26 06/24/21 19:57 .000

Subject Name

Blank Test
Subject I.D.

Deerator Name: I.D.

Deerator Name: I.D.

Deerator Name: I.D.

Clever MO 65631



#### CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 21080 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on March 10, 2021, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1214% (w/vol) ethyl alcohol. The expiration date for this lot number is March 8, 2023 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03052002 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



#### Missouri Department of Health and Senior Services

P.O. Box 570, Jefferson City, MO 65102-0570 Phone: 573-751-6400 FAX: 573-751-6010 RELAY MISSOURI for Hearing and Speech Impaired 1-800-735-2966 VOICE 1-800-735-2466





Michael L. Parson Governor

## SIMULATOR CERTIFICATION REPORT

#### SIMULATOR INFORMATION

Simulator Serial Number: SD2259

Manufacturer: Guth

Model Number:

10-4D

Agency:

CLEVER PD

Agency Address: 304 S CLARKE ST, CLEVER, MO 65631

#### NIST THERMOMETER INFORMATION

Serial Number:

17KMM00690

Bias:

0.00

Uncertainty:

0.02

Date of Certification:

11/6/2020

Date of Expiration: 11/6/2021

### **ENVIRONMENTAL CONDITIONS**

The environmental conditions during testing are within the tolerances of DHSS BAP method 3.

#### VERIFICATION RESULTS

Simulator Average

**NIST Average** 

**Combined Uncertainty** 

33.99

34.00

.03

The combined uncertainty is calculated with a k=2 value.

### ADJUSTMENT RESULTS

No adjustment was needed.

Date of testing:

5/11/2021

**Certification Expiration:** 

5/11/2022

Simulator testing technician: M. BOND

Notes on Condition: none

Deviation(s) from method: none

**DHSS BAP Scientist Approving:** 

B. LUTMER

Certification No:

SD2259 5112021

DHSS BAP Scientist Approving

Simulator Calibration Certification Issued by Lab Manager, DHSS BAP Revision Date: 05/16/2018

Breath Alcohol Program 1903 Northwood Drive, Suite 4 Poplar Bluff, MO 63901

DHSS BAP Document 3.6A Revision 1 Page 1 of 1



## STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES BREATH ALCOHOL PROGRAM



# PERMIT TYPE II **DILLON PETERSEN**

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

## **ALCO-SENSOR IV WITH PRINTER**

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE	5/18/2021	his in se
	010100	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY
NUMBER	210108	
EXPIRES	5/18/2023	- Mill Knight
		DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (6-10)

LAB-4 (R6-10)



PETERSEN, DILLON

Permit No 210108

Date Issued 5/18/2021 Date Expires 5/18/2023

