



ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 111640	PRINTER SN 09B.3589.433	DATE OF INSPECTION 08/12/2021
-----------------------------	----------------------------	----------------------------------

LOCATION OF INSTRUMENT (STREET AND CITY) Riverview Police Department - 9699 Lilac Dr., Riverview, MO	TIME OF INSPECTION 12:40 pm
---	--------------------------------

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

TEMPERATURE OF ALCO SENSOR (10°C - 40°C)

PRINTER WORKING PROPERLY

TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE

STANDARD SUPPLIER Guth Laboratories LOT # 21080 EXP. DATE 03/08/2023

SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0C SIMULATOR SN MP 5535 SIMULATOR EXP DATE 02/22/2022

CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
- 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
- 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 0.102%

TEST 2 0.104%

TEST 3 0.103%

RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

Instrument operating within DOHSS standards

Bottle # 772

INSPECTING OFFICER

SIGNATURE *Patrolman Eddie Lee #311*

PRINT NAME
Patrolman Eddie Lee #311

TYPE II PERMIT NUMBER/EXPIRATION DATE
200182 / 05-26-2022

TELEPHONE NUMBER
(314) 868-9130

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
2875 James Boulevard
Poplar Bluff, MO 63901

AS IU Serial no: 111640
Version no: 532B

TEST RECORD - REPRINT

TEST RECORD 00285

Temp Date Time 210L ^{s/}

Air Blank:
08/12/21 12:42 .000
Calibration Check:
22 08/12/21 12:42 .182

Subject Name

Test 1

Subject I.D.

Operator Name, I.D.

CU 311

Location

AS IU Serial no: 111640
Version no: 532B

TEST RECORD 00286

Temp Date Time 210L ^{s/}

Air Blank:
08/12/21 12:44 .000
Calibration Check:
23 08/12/21 12:44 .184

Subject Name

Subject I.D.

Test 2

Operator Name, I.D.

AS IU Serial no: 111640
Version no: 532B

TEST RECORD 00287

Temp Date Time 210L ^{s/}

Air Blank:
08/12/21 12:46 .000
Calibration Check:
24 08/12/21 12:46 .183

Subject Name

Test 3

Subject I.D.

Operator Name, I.D.

CU 311

Location

AS IU Serial no: 111640
Version no: 532B

TEST RECORD 00288

Temp Date Time 210L ^{s/}

VOID: RFI
12 08/12/21 12:48

Subject Name

RFI

Subject I.D.

Operator Name, I.D.

CU 311

Location



GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number **21080** of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **March 10, 2021**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.1214%** (w/vol) ethyl alcohol. The expiration date for this lot number is **March 8, 2023** at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of **0.100 g/210L +/- 3%**.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03052002 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM



PERMIT
TYPE II
EDDIE LEE

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 5/26/2020

NUMBER 200182

EXPIRES 5/26/2022

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator LEE, EDDIE
Permit No 200182
Date Issued 5/26/2020 **Date Expires** 5/26/2022

