

RECEIVED

By Tracy Crews at 7:27 am, Oct 18, 2021



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY
BREATH ALCOHOL PROGRAM
INTOX DMT MAINTENANCE REPORT

REPORT #1

Complete this report at the time of the regular monthly preventive maintenance check (not to exceed 35 days).
Complete this report whenever the instrument is serviced or repaired and whenever it is placed into service.
Retain the original and send a copy within 15 days to the Breath Alcohol Program, DHSS.

INTOX DMT SN 500080	NAME OF AGENCY Missouri State Highway Patrol	DATE OF INSPECTION 10/09/2021
LOCATION OF INSTRUMENT (STREET AND CITY) 360 CHESTNUT, OSCEOLA, MO		TIME OF INSPECTION 13:11:05

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or is operating within established limits. (Write in observed values where determined). Unmarked items must be corrected before using instrument.

<input checked="" type="checkbox"/> DIAGNOSTIC RECORD	
DATE AND TIME <u>10/09/2021 13:11:08</u>	<input checked="" type="checkbox"/> DETECTOR
<input checked="" type="checkbox"/> PROGRAM	<input checked="" type="checkbox"/> FILTER 1
<input checked="" type="checkbox"/> SAMPLE CHAMBER <u>48.8°C</u>	<input checked="" type="checkbox"/> FILTER 2
<input checked="" type="checkbox"/> BREATH TUBE <u>47.5°C</u>	<input checked="" type="checkbox"/> FILTER 3
<input checked="" type="checkbox"/> PUMP	<input checked="" type="checkbox"/> INTERNAL STANDARD

BREATH ANALYZER ACCURACY STANDARDS	
<input type="checkbox"/> SIMULATOR STANDARD	<input checked="" type="checkbox"/> COMPRESSED ETHANOL-GAS MIXTURE

<input checked="" type="checkbox"/> STANDARD SUPPLIER <u>INTOXIMETERS</u>	LOT # <u>AG011501</u>	EXP. DATE <u>04/24/2022</u>
<input type="checkbox"/> SIMULATOR TEMP (34°C ± 0.2°C) _____	SIM. SN _____	SIM. NIST EXP DATE _____

<input checked="" type="checkbox"/> CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT) Run three tests using a standard. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard being used.	
<input checked="" type="checkbox"/> 0.10% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE	
<input type="checkbox"/> 0.08% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE	
<input type="checkbox"/> 0.04% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE	

TEST 1: 0.096	TEST 2: 0.096	TEST 3: 0.096
---------------	---------------	---------------

<input checked="" type="checkbox"/> PERFORM R.F.I. TEST

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:					
REFUSALS: 0	0-.04: 0	.05-.09: 2	10-.14: 3	.15-.19: 0	OVER .19: 0

LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR MODIFICATION THAT WAS MADE TO RESTORE THE INSTRUMENT TO OPERATE SATISFACTORILY AND WITHIN ESTABLISHED LIMITS (USE OTHER SIDE IF NECESSARY)

INSPECTING OFFICER		
SIGNATURE 	PRINT FULL NAME WILLIAM J WOOD	
TYPE II PERMIT NUMBER 200203	EXPIRATION DATE 07/08/2022	TELEPHONE NUMBER 417-895-6868

RETURN COMPLETED REPORT TO THE	Breath Alcohol Program, Missouri Department of Health and Senior Services by mail, fax, or email
--------------------------------	---



Airgas USA LLC (LAB)
 3500 Bernard Street
 St. Louis, Mo. 63103
 Ph: (314) 533-3100
 Fax: (314) 533-7328

Certificate of Analysis

Customer Name
 Exclusive Supplier
 Intoximeters, Inc.
 2081 Craig Road
 St. Louis, Mo 63146

Test Date: 28-Apr-2020

Lot # AG011501 Model 108cacd

Exp. Date 24-Apr-2022	Cyl. Type 108	Component Ethanol Nitrogen	Certified Concentration 0.100 ± 2% BrAC (260 ppm) Balance
---------------------------------	-------------------------	---	--

Certification Traceable to N.I.S.T. RGM and to CRM Ethanol Standards:

<table border="0" style="width: 100%;"> <thead> <tr> <th style="text-align: left;"><u>RGM Serial No.</u></th> <th style="text-align: left;"><u>Concentration</u></th> </tr> </thead> <tbody> <tr><td>EB0010581</td><td>392.1 ppm</td></tr> <tr><td>EB0010570</td><td>259.8 ppm</td></tr> <tr><td>EB0010285</td><td>208.0 ppm</td></tr> <tr><td>EB0010561</td><td>103.6 ppm</td></tr> <tr><td>EB0010681</td><td>52.12 ppm</td></tr> </tbody> </table> <table border="0" style="width: 100%;"> <thead> <tr> <th style="text-align: left;"><u>CRM Serial No.</u></th> <th style="text-align: left;"><u>Concentration</u></th> </tr> </thead> <tbody> <tr><td>CC434668</td><td>800.0 ppm</td></tr> <tr><td>CC234503</td><td>253.0 ppm</td></tr> </tbody> </table>	<u>RGM Serial No.</u>	<u>Concentration</u>	EB0010581	392.1 ppm	EB0010570	259.8 ppm	EB0010285	208.0 ppm	EB0010561	103.6 ppm	EB0010681	52.12 ppm	<u>CRM Serial No.</u>	<u>Concentration</u>	CC434668	800.0 ppm	CC234503	253.0 ppm	<table border="0" style="width: 100%;"> <thead> <tr> <th style="text-align: left;"><u>RGM Serial No.</u></th> <th style="text-align: left;"><u>Concentration</u></th> </tr> </thead> <tbody> <tr><td>EB0010603</td><td>393.0 ppm</td></tr> <tr><td>EB0010559</td><td>258.2 ppm</td></tr> <tr><td>EB0010595</td><td>208.3 ppm</td></tr> <tr><td>EB0010562</td><td>104.2 ppm</td></tr> <tr><td>EB0010579</td><td>52.81 ppm</td></tr> </tbody> </table> <table border="0" style="width: 100%;"> <thead> <tr> <th style="text-align: left;"><u>CRM Serial No.</u></th> <th style="text-align: left;"><u>Concentration</u></th> </tr> </thead> <tbody> <tr><td>0056649</td><td>390.1 ppm</td></tr> <tr><td>0056662</td><td>150.2 ppm</td></tr> </tbody> </table>	<u>RGM Serial No.</u>	<u>Concentration</u>	EB0010603	393.0 ppm	EB0010559	258.2 ppm	EB0010595	208.3 ppm	EB0010562	104.2 ppm	EB0010579	52.81 ppm	<u>CRM Serial No.</u>	<u>Concentration</u>	0056649	390.1 ppm	0056662	150.2 ppm
<u>RGM Serial No.</u>	<u>Concentration</u>																																				
EB0010581	392.1 ppm																																				
EB0010570	259.8 ppm																																				
EB0010285	208.0 ppm																																				
EB0010561	103.6 ppm																																				
EB0010681	52.12 ppm																																				
<u>CRM Serial No.</u>	<u>Concentration</u>																																				
CC434668	800.0 ppm																																				
CC234503	253.0 ppm																																				
<u>RGM Serial No.</u>	<u>Concentration</u>																																				
EB0010603	393.0 ppm																																				
EB0010559	258.2 ppm																																				
EB0010595	208.3 ppm																																				
EB0010562	104.2 ppm																																				
EB0010579	52.81 ppm																																				
<u>CRM Serial No.</u>	<u>Concentration</u>																																				
0056649	390.1 ppm																																				
0056662	150.2 ppm																																				

Analytical Method: NDIR

Digitally signed by Quality Control
 Date: 2020.04.28 18:14:39 -05 00
 Reason: Dry gas standard certification of analysis
 Location: Airgas USA LLC (Lab)

Approved for Release:



 Rod Marsala

ISO 17025:2005 A2LA accredited. Certificate Number 3082.06
ISO 17034:2016 A2LA accredited. Certificate Number 3082.07



STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

2

PERMIT
TYPE II
WILLIAM J WOOD

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

INTOX DMT

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 7/8/2020

NUMBER 200203

EXPIRES 7/8/2022

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (5-10)

LAB-4 (16-10)

STATE OF MISSOURI
 DEPARTMENT OF HEALTH AND SENIOR SERVICES
 BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator WOOD, WILLIAM
Permit No 200203
Date Issued 7/8/2020 **Date Expires** 7/8/2022