



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
 STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 087976	NAME OF AGENCY Missouri State Highway Patrol	DATE OF INSPECTION 10/02/2024
LOCATION OF INSTRUMENT (STREET AND CITY) 3131 E Kearney, Springfield, Missouri 65803		TIME OF INSPECTION 08:06

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

- DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)
- TEMPERATURE OF ALCO SENSOR (10°C - 40°C)
- PRINTER WORKING PROPERLY
- TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

<input checked="" type="checkbox"/> SIMULATOR SOLUTION	<input type="checkbox"/> COMPRESSED ETHANOL-GAS MIXTURE
<input checked="" type="checkbox"/> STANDARD SUPPLIER <u>Guth Laboratories, INC</u> LOT # <u>23390</u> EXP. DATE <u>10/17/2025</u>	
<input checked="" type="checkbox"/> SIMULATOR TEMPERATURE (34°C ± 0.2°C) <u>33.99</u> SIM. SN <u>MP2418</u> SIM. NIST EXP DATE <u>12/05/2024</u>	

CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)
 Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
- 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
- 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 → <u>.099</u>	TEST 2 → <u>.099</u>	TEST 3 → <u>.098</u>
----------------------	----------------------	----------------------

RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	(0-.04)	(.05-.09)	(.10-.14)	(.15-.19)	(OVER .19)
----------	---------	-----------	-----------	-----------	------------

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

INSPECTING OFFICER	
SIGNATURE 	PRINT NAME D W Henley #727
TYPE II PERMIT NUMBER/EXPIRATION DATE 240144 exp 6/28/2026	TELEPHONE NUMBER (417) 895- 6868

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.

AS IU Serial no: 087976
Version no: 532B

TEST RECORD 00534

Temp Date Time 210L 9/

Air Blank:

10/02/24 08:09 .000

Calibration Check:

19 10/02/24 08:09 .099

Subject Name

TEST 2

Subject I.D.

Operator Name, I.D.

D W HEWLEY # 707

Location

3131 E KEARNEY

SPRINGFIELD, MO

108 # 707

AS IU Serial no: 087976
Version no: 532B

TEST RECORD 00535

Temp Date Time 210L 9/

Air Blank:

10/02/24 08:11 .000

Calibration Check:

20 10/02/24 08:11 .099

Subject Name

TEST 2

Subject I.D.

Operator Name, I.D.

D W HEWLEY # 707

Location

3131 E KEARNEY

SPRINGFIELD, MO

108 # 707

AS IU Serial no: 087976
Version no: 532B

TEST RECORD 00536

Temp Date Time 210L 9/

Air Blank:

10/02/24 08:12 .000

Calibration Check:

21 10/02/24 08:12 .098

Subject Name

TEST 3

Subject I.D.

Operator Name, I.D.

D W HEWLEY # 707

Location

3131 E KEARNEY

SPRINGFIELD, MO

108 # 707

AS IU Serial no: 087976
Version no: 532B

TEST RECORD 00537

Temp Date Time 210L 9/

VOID: RFI

12 10/02/24 08:14

Subject Name

RFI

Subject I.D.

Operator Name, I.D.

D W HEWLEY # 707

Location

3131 E KEARNEY

SPRINGFIELD, MO

109 # 727



STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

2

**PERMIT
TYPE II**

DAVID W. HENLEY, JR.

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX DMT

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 6/28/2024

NUMBER 240144

EXPIRES 6/28/2026

Mike Mason

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

Paula J. Nielson

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (5-10)

LAB-4 (R6-10)



STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator HENLEY, JR., DAVID
Permit No 240144
Date Issued 6/28/2024 **Date Expires** 6/28/2026





GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4611 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 23390 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 18, 2023, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1207% (w/vol) ethyl alcohol. The expiration date for this lot number is October 17, 2025 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.