

## MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

### ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time of t Send copy to Department of Health and Senior S		nce check, and whenever instrument is repaired.				
ALCO SENSOR IV SN 087978	NAME OF AGENCY Owensville PD	DATE OF INSPECTION 10/29/2024				
LOCATION OF INSTRUMENT (STREET AND CITY) 780 West Highway 28 Owensville		TIME OF INSPECTION  12:45 PM				
CHECKLIST: Place a mark in the box by each ite	em if found to be satisfactory or if operating	within established limits. (Write in observed values				
where determined.) Unmarked items must be co	prrected before using instrument.	X				
☑ DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)						
☑ TEMPERATURE OF ALCO SENSOR (10°C - 40°C)						
PRINTER WORKING PROPERLY						
☑ TIME AND DATE DISPLAYING PROPERLY						
BREATH ALCOHOL ACCURACY STANDARDS	S					
☑ SIMULATOR SOLUTION ☐ COMPRESSED ETHANOL-GAS MIXTURE						
STANDARD SUPPLIER Guth Laboratories LOT # 24110 EXP. DATE 03/05/2026						
SIMULATOR TEMPERATURE (34°C ± 0.2°	C) 33.98 SIM. SN MP 705	8 SIM. NIST EXP DATE 10/07/2025				
<ul> <li>✓ CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)</li> <li>Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)</li> <li>✓ 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE</li> <li>✓ 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE</li> <li>✓ 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE</li> </ul>						
TEST 1    .103	ST 2 .102	TEST 3   .102				
☑ RFI DETECTOR OPERATING						
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)						
REFUSALS 0 (004) 0 (	(.1014)	(.1519) <sup>0</sup> (OVER .19) <sup>0</sup>				
List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).  Instrument operating satisfactorily and within established limits.						
INSPECTING OFFICER SIGNATURE		PRINT NAME				
· CWIGHT		Jonathan Scott Griffith				
TYPE II PERMIT NUMBER/EXPIRATION DATE 230060/04-02-2025	TELEPHONE NUMBER (573) 437-2195					
Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office						

by mail, fax, or email.

AS IV Serial no: 087978 Version no: 532B

TEST RECORD 00820

Temp Date Time 210L

Air Blank: 10/29/24 12:45 .000 Subject Test: Auto 21 10/29/24 12:45 .000

Subject Name

Subject I.D.

Blank Test

Operator Name, I.D.

GRIFFITH 104

Location

Owersuille PD

AS IV Serial no: 087978 Version no: 532B

TEST RECORD 00821

Temp Date Time 210L

Air Blank: 10/29/24 12:48 .000 Calibration Check: 21 10/29/24 12:48 .103

Subject Name

Subject I.D.

Operator Name, I.D.

GRIFFITH 101

Location

Owensuille PD

AS IV Serial no: 087978 Version no: 532B

TEST RECORD 00822

Temp Date Time 210L

Air Blank: 10/29/24 12:50 .000 Calibration Check: 22 10/29/24 12:50 .102

Subject Name

Subject I.D.

Check 2

Operator Name, I.D.

GRIFFITH 101

Location

Owersuille PD

AS IV Serial no: 087978 Version no: 532B

TEST RECORD 00823

Temp Date Time 210L

Air Blank: 10/29/24 12:53 .000 Calibration Check: 22 10/29/24 12:53 .102

Subject Name

Check 3

Operator Name, I.D.

GRIFFITH 101

Location

Owensuille PD

AS IV Serial no: 087978 Version no: 532B

TEST RECORD 00824

Temp Date Time 210L

VOID: RFI 12 10/29/24 12:55

Subject Name

Subject I.D.

Check-RFI

Operator Name, I.D.

GRIFFITH 101

Location

Owessville PD



#### CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 24110 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on March 6, 2024, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1215% (w/vol) ethyl alcohol. The expiration date for this lot number is March 5, 2026 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



## STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES · BREATH ALOCHOL PROGRAM



TYPE II

# JONATHAN S. GRIFFITH

is hereby authorized to instruct and supervise operators, tein instructors, inspect, neithrate, perform field service and repairs, and operate the fellowing breath analyzer(s):

ALL		-		
tor the determination of the elochetic 577,020 through 577,041, RSMo an	् व विकास स्थापन	a samula of exp	red six Permit lested under the pro-	risions of sections
DATE : : 4/2/2023	,	, 00	BHEDIOR OF STATE FIELD HEATH LABOR	
NEMBER 230060		, 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	Jane & Maddelor	~
EXPIRES AIDIONS				2月27日2月25日25日25日25日25日25日25日25日25日25日25日25日25日2
加雪岛西红河		~,		•

DEPARTMENT OF HEALTH AND SERVICES O LATE OF TAXABLE AND SERVICES UMENT OPERATOR GARD ed vardholder is authorized to eperate an evidential breath alcohol DBDDES