



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

A Little A					
Complete this report in duplicate at the time of Send copy to Department of Health and Senior				whenev	er instrument is repaired.
ALCO SENSOR IV SN Nixa 095961	NAME OF AGENCY Nixa Police Depa	ırtment		DATE OF 1	NSPECTION 1024
LOCATION OF INSTRUMENT (STREET AND CITY) 715 W Center Circle, Nixa, MO 65714			Т		NSPECTION
CHECKLIST: Place a mark in the box by each it	em if found to be satisf	actory or if operating	<u></u>		
where determined.) Unmarked items must be c					
DIGITAL READOUT (ALL ELEMENTS OPI	ERATIONAL)				
☐ TEMPERATURE OF ALCO SENSOR (10°	C - 40°C)				
PRINTER WORKING PROPERLY					
☑ TIME AND DATE DISPLAYING PROPERL					
BREATH ALCOHOL ACCURACY STANDARD	S				
SIMULATOR SOLUTION	·	☐ COMPRESSE	D ETHANOL-GAS	S MIXTU	JRE
STANDARD SUPPLIER Guth Laboratoric	9S L(OT # <u>23390</u>	EXP. DATE _	10/17/2	025
SIMULATOR TEMPERATURE (34°C ± 0.2°	°C) <u>34.0</u> SIN	M. SN <u>MP 553</u>	57 SIM. NI	ST EXP	DATE <u>07/19/2024</u>
Run three tests using a standard solution. A less. Check the box corresponding to the st 0.100% STANDARD - MUST READ BI 0.080% STANDARD - MUST READ BI 0.040% STANDARD - MUST READ BI	andard solution being ETWEEN 0.095% and ETWEEN 0.076% and	used. (PRINTOUT A 0.105% INCLUSIVE 0.084% INCLUSIVE	ATTACHED) E E		
TEST 1 ★ .100	ST2 * .100		TEST 3100	ı	
RFI DETECTOR OPERATING					
NDICATE THE NUMBER OF BREATH TESTS (DO NOT INCLUDE SELF-ADMINISTERED TE		RANGES SINCE	THE LAST MAIN	TENAN	CE REPORT:
REFUSALS 0 (004) 0	(.0509) 0	(.1014) 0	(.1519)	0	(OVER .19) 0
List any new parts and describe any alteration established limits (use other side if necessary).	or modification that w	as made to restore	the instrument to	operate	satisfactorily and within
NSPECTING CFFICER					
SIGNATURE 403			PRINT NAME Sgt. J Barton		_
YPE II PERMIT NAMBER/EXPIRATION DATE 230030 02/17/2025			TELEPHONE NUMBER (417) 725-2510)	
Return completed report to the: Breath Alcol by mail, fax,	hol Program, MO Dep or email.	artment of Health an	<u> </u>		east District Office

Nixa Police Department

Calibration Check slip's

Versi	on no:	532B		The second secon
TE	ST RECO	RD 028	341 97	
Temp	Date	Time		
	5/20/24		.000	600 mmann mmann m
	ration (5/20/24		.100	
	t Name	2		
	t I.D.			
)perat	or Name	e, I.D.		•
.ocatj		> 463		
	Ai.			\$

AS IV Serial no: 095961
Version no: 532B

TEST RECORD 02842
9/
Temp Date Time 210L
Air Blank: 05/20/24 00:27 .000
Subject Test: Man 27 05/20/24 00:27 .100

Subject Name

TEST 2
Subject I.D.

Operator Name, I.D.
Location

AS IV Versio				959	961
VW) W 21	241 110				
TES	ST RE	CORI	0 02	284:	3 9/
Теме	Dat	e	Time	e 1	~.
Air B	lank:				
	5/20/	24 (30: 29).(300
Subjec	t Te	st:	Man		
28 0	5/20/	24 (30:29) .	100
Subjec	t Na	me			
-7	est	. 5			
Subjec					
OMBAE	_'	D.			
Operat	tor N	ame	. 1.1	n.	
OF GI G	7/			-	
	7_	2_	<u>463</u>		
Locat	ion				

Nixa Police Department

RFI Evidence slip

oc tu	Carial	00	E061
ns IV Versi	seriai on no:	no: 09 532B) 10¢C
TES	ST RECO	RD 028	9/
Темр	Date	Time	210L
VOID: 12 05	RFI 5/20/24	00:36	
	t Name		
	CFT t I.D.		
Operat	or Nam	e, I.D.	· • • • • • • • • • • • • • • • • • • •
<u> </u>		, 403	
	 -		<u>-</u>

Nixa Police Department

Blank (Zero) test Evidence slip

	on no: ST RECO	532B RD 028	145 9/
Ceme	Date	Time	~ •
Dub inc	5/20/24 + Tost	00:38 : Auto : 00:38	
E	t Name CIAN t I.D.	<u>k</u>	
Opera Locat	\mathscr{A}_{-}	403	



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 23390 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 18, 2023, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1207% (w/vol) ethyl alcohol. The expiration date for this lot number is October 17, 2025 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT TYPE II

JOSHUA C. BARTON

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES BREATH ALCOHOL PROGRAM

INSTRUMENT OPERATOR CARD

The named caroholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired all in bussoud.

Operator

BARTON, JOSHUA

Permit No 230030 Date Issued 2/17/2023

Date Expires 2/17/2025

