



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

MBCCCX						
Complete this report in d Send copy to Departmen	uplicate at the time t of Health and Seni	of the regular monthly or Services; retain origi	preventative maintena nal in department file.	nce check, and whene	ver instrument is repaired.	
ALCO SENSOR IV SN 107975	,	NAME OF AGENCY Stoddard County	/ SO	DATE OF 12/10/2	INSPECTION 2024	
LOCATION OF INSTRUMENT (207 South Prairie, Block		-		TIME OF 9:21 a	INSPECTION M	
CHECKLIST: Place a ma	rk in the box by each	item if found to be satis	sfactory or if operating v	vithin established limits	. (Write in observed values	
where determined.) Unm	arked items must be	corrected before using				
DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)						
✓ TEMPERATURE OF ALCO SENSOR (10°C - 40°C)						
✓ TIME AND DATE DISPLAYING PROPERLY						
BREATH ALCOHOL AC	CURACY STANDAR	RDS				
✓ SIMULATOR SOLUTION ☐ COMPRESSED ETHANOL-GAS MIXTURE					URE	
✓ STANDARD SUPPL	IER Guth Laborato	ories L	EXP. DATE <u>03/05/2026</u>			
SIMULATOR TEMPERATURE (34°C \pm 0.2°C) 34.01 SIM. SN MP7053 SIM. NIST EXP DATE 08/28/2025						
✓ 0.100% STAND,☐ 0.080% STAND,	ARD - MUST READ ARD - MUST READ	standard solution bein BETWEEN 0.095% an BETWEEN 0.076% an BETWEEN 0.038% an	d 0.105% INCLUSIVE d 0.084% INCLUSIVE	TACHED)		
TEST 1 .101		TEST 2 .099		TEST 3 .097		
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)						
REFUSALS	(004)	(.0509)	(.1014)	(.1519)	(OVER .19)	
List any new parts and d	escribe any alteration	n or modification that y		(inotrume and to an and	e satisfactorily and within	
established limits (use oth	ner side if necessary).	was made to restore to	ie instrument to operat	e sausiactorily and within	
INSPECTING OFFICER						
SIGNATURE				RINT NAME		
, 5/1			Zachary Matney			
TYPE II PERMIT NUMBER/EXPIRATI 240194 08/29/2026			TELEPHONE NUMBER (573) 568-4654			
Return completed repor	t to the: Breath Ald	cohol Program, MO De ax, or email.	partment of Health and	Senior Services, Sout	heast District Office	

AS IV Serial no: 107975 Version no: 532B TEST RECORD 00726 Temp Date Time 210L Air Blank: 12/10/24 09:21 .000 Calibration Check: 14 12/10/24 09:21 .101 Subject Name Test 1 Subject I.D.

Operator Name, I.D.

Location

SUSO

Z.M. Matricy # 240194

AS IV Serial no: 107975 Version no: 532B TEST RECORD 00727 Time 210L Temp Date Air Blank: 12/10/24 09:23 .000 Calibration Check: 16 12/10/24 09:23 .099 Subject Name TEST 2 Subject I.D.

Operator Name: I.D. Z.M. Matry 4 240194 Location 5050

Version no: 532B TEST RECORD 00728 Temp Date Time 210L Air Blank: 12/10/24 09:25 .000 Calibration Check: 18 12/10/24 09:25 .097 Subject Name Test 3

AS IV Serial no: 107975

Operator Name: I.D. Z.M. Motory #240194 Location 5050

Subject 1.D.

AS IV Serial no: 107975 Version no: 532B

TEST RECORD 00729

Temp Date Time 210L VOID: RFI 12 12/10/24 09:29

Subject Name

RFI Test Subject I.D.

Operator Name, I.D. 7.M.14 atney #241941 Location

5050



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 24110 of
Alcohol Reference Solution for Simulator were analyzed by
gas chromatography on March 6, 2024, using a Perkin Elmer Gas
Chromatograph Autosystem XL S/N: 610N9030209, and found to contain
0.1215% (w/vol) ethyl alcohol. The expiration date for this lot
number is March 5, 2026 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT

ZACHARY MATNEY

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX DMT

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE8/29/2024	Mike Massur
NUMBER 240194	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY
EXPIRES 8/29/2026	Davea J. Michaelson
MO 580-0771 (6-10)	DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES
	I AD A /Do 40

