

## MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

#### **ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT**

REPORT #7

Complete this report in d Send copy to Departmen	luplicate at the time at of Health and Ser	of the regunior Services	lar monthly ; retain orig	preventa inal in de	tive mainter partment file	nance check, and e.	l whenever i	nstrument is repaired.	
ALCO SENSOR IV SN		NAME OF AGENCY NORMANDY PD			y PD	14.00	DATE OF INSPECTION 06/12/2024		
LOCATION OF INSTRUMENT (STREET AND CITY) 7700 Natural Bridge Rd. Normandy, Mo 63121							TIME OF INSP		
CHECKLIST: Place a ma where determined.) Unm	rk in the box by eac	h item if four	d to be satis	factory o	r if operating	g within establishe	ed limits. (Wi	rite in observed values	
DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)									
TEMPERATURE OF ALCO SENSOR (10°C - 40°C)									
PRINTER WORKING PROPERLY									
TIME AND DATE DISPLAYING PROPERLY									
BREATH ALCOHOL ACCURACY STANDARDS									
SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE									
STANDARD SUPPLIER Guth Laboratorics Inc LOT # 23390 EXP. DATE 10/17/2025								15	
SIMULATOR TEMPE	ERATURE (34°C ±	0.2°C) <u>34</u> .	<u>دی</u> sı	M. SN	SD1618	SIM. N	IST EXP DA	TE 05/21/2025	
less. Check the box of 0.100% STAND, 0.080% STAND,	a standard solutio	n. All three to standard so BETWEEN BETWEEN	ests must b olution being 0.095% an 0.076% an	e within : g used. (f d 0.105% d 0.084%	±5% of the s PRINTOUT A INCLUSIV INCLUSIV	standard value ai ATTACHED) E E	nd must hav	e a spread of .005 or	
TEST 1 - 0.10a		TEST 2 - 0.104			TEST 3 - 0.104				
RFI DETECTOR OPE	ERATING								
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)									
REFUSALS	(004)	(.0509)		(.1014	)	(.1519)	(0)	/ER .19)	
List any new parts and d	<u> </u>		cation that v						
established limits (use oth	ner side if necessar	y).					o operate su		
			museum en						
INSPECTING OFFICER SIGNATURE 337						PRINT NAME Ryan Mack			
TYPE II PERMIT NUMBER/EXPIRATION DATE						TELEPHONE NUMBER (630 ) 427-7521			
द्वारा है।	t to the: Breath A by mail,	lcohol Progra ax, or email	am, MO Dep	partment	of Health ar	/		st District Office	
O 580-1351 (5-19)									

AS IV Serial no: 111647 Version no: 532B

TEST RECORD 00454

Temp Date Time 210L

Air Blank: 06/12/24 19:09 .000 Calibration Check: 22 06/12/24 19:09 .102

Subject Name

Test#1

Subject I.D.

Maintenance

Operator Name: I.D.

Ryan Mack /240121

Location

7700 Natural Bridge Rd

Normandy, Mo 63121

AS IV Serial no: 111647 Version no: 532B

TEST RECORD 00455

Temp Date Time 210L

Air Blank: 06/12/24 19:11 .0

Calibration Check: 22 06/12/24 19:11 .104

Subject Name

Test #2

Subject I.D.

Maintenance

Operator Name, I.D.

Ryan Mack / 240121

Location

7700 Natural Bridge Rol.

Normandy, Mo 63121

AS IV Serial no: 111647 Version no: 532B

TEST RECORD 00456

Temp Date Time 210L

Air Blank:

06/12/24 19:13 .000 Calibration Check: 22 06/12/24 19:13 .104

Subject Name

Test #3

Subject I.D.

Main tenance

Operator Name, I.D.

Ryan Mack / 240121

Location

7700 Natural Bridge Rd

Normandy, Mo 63-121

AS IV Serial no: 111647 Version no: 532B

TEST RECORD 00452

Temp Date Time 210L VOID: RFI 12 06/12/24 19:14

Subject Name

RFI Test

Subject I.D.

Maintenance

Operator Name, I.D.

Ryan Mack 1240121

Location

7700 Natural Bridge Rd

Normandy Mo 63121



## CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 23390 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 18, 2023, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1207% (w/vol) ethyl alcohol. The expiration date for this lot number is October 17, 2025 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- ...2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



## STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



# PERMIT TYPE II

# RYAN MACK

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

# **ALCO-SENSOR IV WITH PRINTER**

NUMBER 240121

EXPIRES 5/29/2026

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

Daves I. Nichelson

LAB-4 (R6-10)

MO 580-0771 (6-10)



The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator MACK, RYAN Permit No 240121

Date Issued 5/29/2024 Date Expires 5/29/2026

