



REPORT #7

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

Complete this report in do Send copy to Department	물에도 하다면 하셨다면 하게 하는 것 같아 없다는 아내가 되는데, 그렇게 없다고 하네요.				ver instrument is repaired.		
alco sensor iv sn 111657		NAME OF AGENCY Missouri State Highway Patrol			INSPECTION 4/2024		
LOCATION OF INSTRUMENT (S				TIME OF	INSPECTION  a.m.		
CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values							
where determined.) Unmarked items must be corrected before using instrument.							
▼ DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)							
TEMPERATURE OF ALCO SENSOR (10°C - 40°C)							
PRINTER WORKING	PROPERLY						
TIME AND DATE DIS	SPLAYING PROPE	RLY					
BREATH ALCOHOL ACC	CURACY STANDA	RDS					
SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE							
STANDARD SUPPLI	ER Guth Labo	ratories, Inc.	OT#_23390	EXP. DATE _10/1	7/2025		
SIMULATOR TEMPE	RATURE (34°C ±	0.2°C) <u>33.98</u> SII	м. sn <u>MP2216</u>	SIM. NIST EX	P DATE 11/28/2024		
less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)  □ 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE  □ 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE  □ 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE							
TEST 1 • .102		TEST 2 <b>▼</b> .103		TEST 3 <b>▼</b> .103			
RFI DETECTOR OPE	RATING						
INDICATE THE NUMBER			G RANGES SINCE	THE LAST MAINTENA	NCE REPORT:		
REFUSALS 0	(004) 0	(.0509) 0	(.1014) 1	(.1519) 0	(OVER .19) 0		
List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).							
2-1-1-1							
INSPECTING OFFICER					<b>联系在委员会公司</b>		
SIGNATURE #13	40		Cpl. W.J. Luzenko #1340				
TYPE II PERMIT AUMBER/EXPIRATION DATE 240141 / 6/21/2026				(816) 622-0800			
Return completed repo		Alcohol Program, MO De fax, or email.	partment of Health a	nd Senior Services, Sou	utheast District Office		

Version no:	532B
TEST REC	ORD 00621
Temp Date	9/ Time 210L
Air Blank:	4 10:10 000
Calibration	4 10:13 .000 Check: 4 10:13 .102
Subject Nam	
Maint Fest	
Subject I.D	•
Operator Na	
COLWJ. LUZEN	nko (240141)
Location Cass County 2	
Cass comy 2	one office
AS IV Seria Version no:	1 no: 111657 532B
TEST REC	ORD 00623
Temp Date	9/ Time 210L
Air Blank:	4 10:16 .000
Calibration	Check:
	4 10:16 .103
Subject Nam	#0
Morint 1899 Subject I.I	
5	T D
Operator Na	7700k (240141)
Location	Jzenko (240141)
Cass Count	2 Zone Office

AS IV Serial no: 111657 Version no: 532B				
TEST RECORD 00622				
Temp Date Time 210L				
Air Blank: 10/24/24 10:15 .000				
Calibration Check: 26 10/24/24 10:15 .103				
Subject Name				
Maint Test # 2 Subject I.D.				
Operator Name, I.D.				
Col. W.J. Wzenko (246141)				
Location Cass County Zone Office				
Cass County Love Ottice				
AS IV Serial no: 111657 Version no: 532B				
TEST RECORD 00624				
Temp Date Time 210L				
VOID: RFI 12 10/24/24 18:17				
Subject Name				
RFI Test Subject I.D.				
oubsect 1.B.				
Operator Name, I.D.				
(11171.1/1.1)				
[pl, W.J. Luzenko (240141)				
Cols County Zone Office				



#### CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 23390 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 18, 2023, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1207% (w/vol) ethyl alcohol. The expiration date for this lot number is October 17, 2025 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



#### STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES BREATH ALCOHOL PROGRAM



# PERMIT TYPE II

## WALTER J. LUZENKO

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

### ALCO-SENSOR IV WITH PRINTER, INTOX DMT

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections

577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.	ma a ma
DATE6/21/2024	Mike Mason
	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY
NUMBER 240141	
EXPIRES 6/21/2026	Davla J. nelselson
	RECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (6-10)

LAB-4 (R6-10)



The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator LUZENKO, WALTER Permit No

240141

Date Issued 6/21/2024 Date Expires 6/21/2026

