By Tracy Crews at 12:25 pm, May 30, 2024



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Where the state of							TILL OITT #1	
Complete this report in dup Send copy to Department of					d whene	ver instrument is	repaired.	
ALCO SENSOR IV SN 111762		PRINTER SN 09B.3589.487				DATE OF INSPECTION 05/13/2024		
LOCATION OF INSTRUMENT (STREET AND CITY) 110 South Maple St Galena					TIME OF INSPECTION 2:32 pm			
CHECKLIST: Place a mark	in the box by each	item if found to be sa	tisfactory or if oper	ating within establi	3		rved val-	
ues where determined.) Unmarked items must be corrected before using instrument.								
DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)								
TEMPERATURE OF ALCO SENSOR (10°C - 40°C)								
PRINTER WORKING PROPERLY								
TIME AND DATE DISPLAYING PROPERLY								
BREATH ALCOHOL ACCU	JRACY STANDARI	DS						
☑ SIMULATOR SOLUTIO	SED ETHANOL-GA	ED ETHANOL-GAS MIXTURE						
STANDARD SUPPLIE	R Guth		OT # 23390	EXP. DATE	10/17/2	2025		
SIMULATOR TEMPER	ATURE (34°C ± 0.2	2°C)34.0SIM	IULATOR SN	MP6027 SIMUL	_ATOR E	EXP DATE <u>03/04</u>	/2025	
0.080% STANDAF	responding to the s RD - MUST READ E RD - MUST READ E		g used. (PRINTOU d 0.105% INCLUS d 0.084% INCLUS	T ATTACHED) IVE IVE	ind must	have a spread o	f .005 or	
TEST 1 • .100		EST 2 .099		TEST 3 .09	TEST 3 .098			
RFI DETECTOR OPER	ATING						11	
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)								
L'	004) 0	(.0509) 0	(.1014) 0	(.1519)	0	(OVER .19)	0	
List any new parts and des established limits (use othe			was made to resto	re the instrument t	o operat	e satisfactorily ar	id within	
INSPECTING OFFICER								
SIGNATURE					PRINT NAME Kyle Stults			
TYPE II PERMIT NUMBER/EXPIRATION 03/22/2026 240 0						TELEPHONE NUMBER (417) 294-4023		
Return completed report t	to the: Breath Alco 2875 Jame	ohol Program, MO De es Boulevard ff. MO 63901	partment of Health			heast District Offic	ce	

AS IV Serial no: 111762 Version no: 532B

TEST RECORD 00787

9/ Time 210L Temp Date

Air Blank: 05/13/24 14:28 .000 Calibration Check: 23 05/13/24 14:28 .000

Subject Name

Selftest Subject I.D.

monthly Ment Operator Name: I.D.

K. Stalls 240070 Location

Stone Co Jail

AS IV Serial no: 111762 Version no: 532B

TEST RECORD 00788

9/ Time 210L

Air Blank: 05/13/24 14:30 .000 Calibration Check: 23 05/13/24 14:30 .100

Subject Name

Tost 1

Subject I.D.

Monthly Maint Operator Name, I.D.

K. stults 240070

Stone Co Jail

TEST RECORD 00789

AS IV Serial no: 111762

Version no: 532B

Temp Date Time 210L

Air Blank:

05/13/24 14:32 .000

Calibration Check: 24 05/13/24 14:32 .099

Subject Name

Tost 2

Subject I.D.

Monthly Maint Operator Name: I.D.

K. Stules 240010

Stone lo Juil

AS IV Serial no: 111762 Version no: 532B

TEST RECORD 00790

9/ Temp Date Time 210L

Air Blank: 05/13/24 14:34 .000 Calibration Check: 24 05/13/24 14:34 .098

Subject Name

Test 3 Subject I.D.

Monthly Marnt

K.Stalts

Location

Stone Co Sail

AS IV Serial no: 111762 Version no: 532B

TEST RECORD 00791

Temp Date

VOID: RFI 12 05/13/24 14:36

Subject Name

PFI

Subject I.D.

Monthly Marat

Operator Name, I.D.

K.Stalks

Stone lo Jail

Stone County Sheriff's Office monthly Maint CPL KyleStults Parmit# 240070 EXP Date: 03/22/2026



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 23390 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 18, 2023, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1207% (w/vol) ethyl alcohol. The expiration date for this lot number is October 17, 2025 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT TYPE II

KYLE G. STULTS

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections

57.7.020 (nrough 577.041, K5Mo and 306.111 through 306.119 K5Mo.	Mike Massin		
DATE	3/22/2024	Mike Massin		
		DIRECTOR OF STATE PUBLIC HEALTH LABORATORY		
NUMBER	240070	Davla I. nichelson		
EXPIRES	3/22/2026	Tavea 3. 1 parcelson		

MO 580-0771 (6-10)

LAB-4 (R6-10)

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES



The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator STULTS, KYLE Permit No 240070

Date Issued 3/22/2024 Date Expires 3/22/2026

