

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

RECEIVED By Tracy Crews at 7:24 am, Jul 15, 2024

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time Send copy to Department of Health and Sen				ver instrument is repaired.	
ALCO SENSOR IV SN	NAME OF AGENCY Missouri State Hi	ghway Patrol	DATE OF 07/14/2	INSPECTION 2024	
LOCATION OF INSTRUMENT (STREET AND CITY) Zone 4/15 Office - 275 B Southwest Outer Road, Branson TIME OF INSPECTION 11:08 pm					
CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.					
DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)					
✓ TEMPERATURE OF ALCO SENSOR (10°C - 40°C)					
✓ PRINTER WORKING PROPERLY					
✓ TIME AND DATE DISPLAYING PROPERLY					
BREATH ALCOHOL ACCURACY STANDA	RDS				
✓ SIMULATOR SOLUTION ☐ COMPRESSED ETHANOL-GAS MIXTURE					
STANDARD SUPPLIER Guth Laboratories LOT # 23390 EXP. DATE 10/17/2025				2025	
✓ SIMULATOR TEMPERATURE (34°C ± 0	0.2°C) 33.99 SII	и. SN MP242	2 SIM. NIST EX	P DATE 12/05/2024	
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE					
TEST 1 .103	TEST 2 .102		TEST 3 .102		
☑ RFI DETECTOR OPERATING					
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)					
REFUSALS 0 (004) 0	(.0509) 0	(.1014) 0	(.1519) 0	(OVER .19) 0	
List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary). Calibrated Changed Printer Paper					
INSPECTING OFFICER PRINT NAME					
SIGNATURE THE			Brandon Hall		
TYPE II PERMIT NUMBER/EXPIRATION DATE 230011 / 01/24/2025			TELEPHONE NUMBER (417) 895-6868		
Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.					

AS IV Serial not i11273 Version not 5328

TEST RECORD 00213
9/
Temp Date Time 210L
Air Blank:

mir Bians 87/14/24 23:06 .000 Calibration: 25 87/14/24 23:06 .100

Subject Name

Acc check

Subject I.D.

Brandon Hall 347

Operator Names I.D.

Zone 4/15 office

Location

Branson

AS IV Serial no: 111773 Version no: 582B

TEST RECORD 00214

Temp Date Time 2101
Air Blank: 07/14/24 23:08 .000
Calibration Check: 126 02/14/24 23:08 .103

Subject Hame

Acc Check

Subject I.D.

Brandon Hall 347.

Operator Mames I.D.

Zone 4/15 office

Location

Branson

AS IV Seria) no: 111273 Version no: 532B

TEST RECORD 00215

Temp Date Time 210L

87/14/24 23:12 .000 Calibration Check: 26 82/14/24 23:12 .182

Subject Name

ACC Check

Subject I.D.

Brandon Hall 347

Operator Names L.D.

Zone 4/15 office

Location

Branson

AS IV Serial not 111773 Version not 532B

TEST RECORD 00216

Temp Date Time 210L

Air Blank: 07/14/24 23:16 .000 Calibration Check: 26 02/14/24 23:16 .102

Subject Name

Acc Check

Subject I.D.

Brandon Wall 347

Operator Names I.D.

Zone 4/15 office

Location

Branson

AS IV Serial not 111773 Version not 532B

TEST RECORD 00217

Temp Date Time 218

VOID: RFI

12-89/14/24 23/19

Subject Home

Acc Check

Subject I.D.

Brandon Hall 347

Operator Names J.D.

Zone 4/15 Office

Location

Branson



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 23390 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 18, 2023, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1207% (w/vol) ethyl alcohol. The expiration date for this lot number is October 17, 2025 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT TYPE II

BRANDON A. HALL

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX DMT

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE	1/24/2023	Mike Massim		
D/((E)		DIRECTOR OF STATE PUBLIC HEALTH LABORATORY		
NUMBER	230011			
EXPIRES	1/24/2025	Davla I. Nichelson		
		DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES		

MO 580-0771 (6-10)

LAB-4 (R6-10)



The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.

Operator HALL, BRANDON

Permit No 230011

