



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in a Send copy to Department	duplicate at the time nt of Health and Ser	of the regular monthly nior Services; retain orig	preventative mainter	nance check, and when	ever instrument is repaired.		
ALCO SENSOD IV CAL	20502	NAME OF AGENCY DOI-National Pa		DATE O	F INSPECTION		
LOCATION OF INSTRUMENT 8928 State Highway 1	9, Winona, Misso	uri 65588		TIME O	-2024 FINSPECTION		
CHECKLIST: Place a ma where determined.) Unm	ark in the box by each	h item if found to be satis	sfactory or if operating	within established limit	s. (Write in observed values		
DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)							
✓ TEMPERATURE OF ALCO SENSOR (10°C - 40°C) / 7							
PRINTER WORKING	PRINTER WORKING PROPERLY						
☑ TIME AND DATE DISPLAYING PROPERLY							
BREATH ALCOHOL AC	CURACY STANDA	RDS					
✓ SIMULATOR SOLUTION ☐ COMPRESSED ETHANOL-GAS MIXTURE							
STANDARD SUPPLIER Guth Laboratories LOT # 23180 EXP. DATE 05/17/2025							
☑ SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.00 SIM. SN MP7615 SIM. NIST EXP DATE 10/24/2025							
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE							
TEST 1 = ,097		TEST 2 ≈ .097		TEST 3 = , 097			
RFI DETECTOR OPE	RATING		A				
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)							
REFUSALS	(004)	(.0509)	(.1014)	(.1519)	(OVER .19)		
List any new parts and destablished limits (use oth	escribe any alteratic ner side if necessary	on or modification that v	vas made to restore	the instrument to opera	te satisfactorily and within		
INSPECTING OFFICER							
1 Tall	He			PRINT NAME Zachary Swindle			
230181 08/17/2025	ON DATE			TELEPHONE NUMBER (573) 351-9645			
Return completed report	t to the: Breath Ald by mail, fa	cohol Program, MO Depax, or email.	partment of Health an		theast District Office		

AS IV Serial no: 120F02 Version no: 532C TEST RELUMI 00110	Air Blank; 24 11.34 O(1)	5.61 - 1 Now Ship Sale Ship Ship Ship Ship Ship Ship Ship Ship	Introduction Religious Scarcon Location 1978 STATE HEN PA
	000		22
	Temp Date Time 210L Temp Air Blank: Air Blank: Air Blank: Callbration Check: Callbration	Subject Name Subject Name Subject 1.D. 230/5/ 5/17/25 Operator Name, 1.D.	~ ? ·

Subject Name 5325

TEST RETURN OF THE 29/2

Subject Name

Subj



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 23180 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on May 18, 2023, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1220% (w/vol) ethyl alcohol. The expiration date for this lot number is May 17, 2025 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN11172002 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT TYPE II

ZACHARY SWINDLE

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX DMT

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE8/17/2023	Mike Massmi
	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY
NUMBER 230181	
EXPIRES 8/17/2025	Davla I. Nichelson
MD 500 0774 (5 40)	DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (6-10)

LAB-4 (R6-10)

