RECEIVED

By Tracy Crews at 8:28 am, Nov 19, 2024



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY BREATH ALCOHOL PROGRAM

INTOX DMT MAINTENANCE REPORT

REPORT #

RETURN COMPLETED REPORT TO THE Breath Alcohol Program, Missouri Department of Health and Senior Services by mail fax or email	
240176 08/19/2026 573-368-2345	
TYPE LIBERT TAMBEER EXPRATION DATE TELEPHONE NUMBER	
S SHATURE PRINT FULL NAME JON-YVES E BELLERS	
INSPECTING OFFICER	
Time adjusted	
LIST ANY NEW PARTS ALD DESCRIBE ANY ALTERATION OR MODIFICATION, THAT WAS MADE TO RESTORE THE INSTRUMENT TO OPERATE SATISFACTORILY AND WITHIN ESTABLISHED LIMITS (USE OTHER SIDE IF NECESSARY)	
INCLUSIAGES OF THE PROPERTY OF	R 19 2
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REF	PORT
☑ PERFORM R.F.I TEST	
TEST 1 0.099 TEST 2 0.099 TEST 3 0.099	
0 04% STANDARD - MUST READ BETWEEN 0.038% AND 0 042% INCLUSIVE	
0 08% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE	
of 005 or less. Mark the box corresponding to the standard being used ☑ 0 10% STANDARD - MUST READ BETWEEN 0.095% AND 0 105% INCLUSIVE	
CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT) Run three tests using a standard. All three tests must be within ±5% of the standard value and must have a spread	
SIMULATOR TEMP (34°C ± 0 2°C) SIM. SN SIM. NIST EXP DATE	
STANDARD SUPPLIER INTOXIMETERS LOT # AG335303 EXP DATE 12/19/202	25
☐ SIMULATOR STANDARD ☐ COMPRESSED ETHANOL-GAS MIXTURE	
BREATH ANALYZER ACCURACY STANDARDS	
☑ BREATH TUBE 48.1°C ☑ FILTER 3	
SAMPLE CHAMBER 48.7°C	
☑ PROGRAM ☑ FILTER 1	
DATE AND TIME 11/02/2024 15:39:03 © DETECTOR	
□ DIAGNOSTIC RECORD	
CHECKLIST: Place a mark in the box by each item if found to be satisfactory or is operating within established limits. (Write in obvalues where determined). Unmarked items must be corrected before using instrument	bserved
Phelps County Jail, 500 W. 2nd Street, Rolla	
500073 Missouri State Highway Patrol 11/02/2024	
INTEX DIVI ST. NAME OF AGENCY DATE OF INSPECTION.	
Complete this report whenever the instrument is serviced or repaired and whenever it is placed into service. Retain the original and send a copy within 15 days to the Breath Alcohol Program, DHSS	
Complete this report at the time of the regular monthly preventive maintenance check (not to exceed 35 days).	