

# MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

### ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

- Stiller.					
Complete this report in duplicate at the time Send copy to Department of Health and Ser				whenever instrument is repaired.	
ALCO SENSOR IV SN 111773	NAME OF AGENCY Missouri State Highway Patro		63	DATE OF INSPECTION 03/05/2025	
LOCATION OF INSTRUMENT (STREET AND CITY) 3131 E Kearney, Springfield, Missouri 65803				TIME OF INSPECTION 12:14	
CHECKLIST: Place a mark in the box by each		actory or if operating	within establishe	d limits. (Write in observed values	
where determined.) Unmarked items must be	e corrected before using	instrument.			
DIGITAL READOUT (ALL ELEMENTS	OPERATIONAL)				
TEMPERATURE OF ALCO SENSOR (10°C - 40°C)					
PRINTER WORKING PROPERLY					
TIME AND DATE DISPLAYING PROPERLY					
BREATH ALCOHOL ACCURACY STANDARDS					
SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE					
STANDARD SUPPLIER Guth Labor	atories, INC LO	OT # 24310	EXP. DATE	08/27/2026	
SIMULATOR TEMPERATURE (34°C ±	<sub>0.2°C)</sub> 33.99 SIN	M. SN MP2418	SIM. NI	ST EXP DATE 12/04/2025	
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)  0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE  0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE  0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE					
TEST 1 <b>-</b> .098	TEST 2 <b>-</b> .098		TEST 3 <b>-</b> .09	8	
✓RFI DETECTOR OPERATING					
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)					
REFUSALS (004)	1	(.1014)	(.1519)	(OVER .19)	
List any new parts and describe any alterati			CASCINITION OF THE CASC		
established limits (use other side if necessar	y).				
***					
change	ed tim	1e +	1 m	ninute	
INSPECTING OFFICER SIGNATURE # 72 -			PRINT NAME D. VA	Llonloy #707	
			D W Henley #727		
240144 Expires 6/28/2026			TELEPHONE NUMBER ( 417 ) 895- 6868		
Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.					

AS IV Serial no: 111773

Version no: 532B

TEST RECORD 00264

Sy

Temp Date Time 210L

Air Blank: 03/05/25 12:15 .000

Calibration Check: 21 03/05/25 12:15 .000

Subject Name

TEST 2

Operator Name, I.D.

Subject I.D.

D W HEWEY #727 Location 313) E KEARNEY

Sparwerseld mo

AS IV Serial no: 111773 Version no: 532B The Contract of the last

• ;

TEST RECORD 00265

Sylvantion Check:
21 03/05/25 12:16 .000

Subject Name

JEST Z

Subject I.D.

Derator Name, I.D.

| W | HENLEY#727

3)3) E KEARNEY

SULTA & TIELD MO

AS IV Serial no: 111773
Version no: 532B

AS IV Serial no: 111773 Version no: 5328

TEST RECORD 00267

TEST RECORD 00266

S/
Temp Date Time 2101

Air Blank: 03/05/25 12:17 .000

Calibration Check: 21 03/05/25 12:17 .098

Temp

Date Time 210L

VOID: RFI 12 03/05/25 12:19

Subject Name

| FST | 3

Subject I.D.

Operator Name, I.D.

S W #FWLEY #127

Location

3131 E KEARNEY

Sperketterd mo

Subject Name

QFI

Subject I.D.

Deerator Name, I.D.

| W | HENDEY # 787

Location

313) E | KEARNEY

SpatusField MO



#### CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 24310 of
Alcohol Reference Solution for Simulator were analyzed by
gas chromatography on August 28, 2024, using a Perkin Elmer Gas
Chromatograph Autosystem XL S/N: 610N9030209, and found to contain
0.1209% (w/vol) ethyl alcohol. The expiration date for this lot
number is August 27, 2026 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

ï

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Culibration verification is done prior to each use utilizing NIST traceable weights.



### STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



## PERMIT TYPE II

## DAVID W. HENLEY, JR.

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

### ALCO-SENSOR IV WITH PRINTER, INTOX DMT

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE6/28/2024	Mile Mason		
	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY		
NUMBER 240144			
EXPIRES 6/28/2026	Daves I. nichelson		
	DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES		

MO 580-0771 (6-10)

LAB-4 (R6-10)

