

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

The second					11=11 0111 27
Complete this report in du Send copy to Department					ver instrument is repaired.
ALCO SENSOR IV SN 119729		NAME OF AGENCY Newton County Sheriff's Office		DATE OF 01/22	INSPECTION 2025
LOCATION OF INSTRUMENT (S 208 W Coler Street, No					INSPECTION am
CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.					
☑ DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)					
☑ TEMPERATURE OF ALCO SENSOR (10°C - 40°C)					
✓ PRINTER WORKING PROPERLY					
☑ TIME AND DATE DISPLAYING PROPERLY					
BREATH ALCOHOL ACCURACY STANDARDS					
Z SIMULATOR SOLUTION COMPRESSED ETHANOL-GAS MIXTURE					
STANDARD SUPPLIER Guth Laboratories, Inc. LOT # 24310 EXP. DATE 08/27/2026					
SIMULATOR TEMPERATURE (34°C \pm 0.2°C) 34.0 SIM. SN DR 6930 SIM. NIST EXP DATE 07/23/2025					
less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) ✓ 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE ○ 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE ○ 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE					
TEST 1 .102		TEST 2 🕶 .101		TEST 3 .102	
RFI DETECTOR OPE	ERATING				
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)					
REFUSALS	(004)	(.0509)	(.1014)	(.1519)	(OVER .19)
List any new parts and d established limits (use oth			vas made to restore	the instrument to opera	ate satisfactorily and within
INSPECTING OFFICER					
SIGNATURE				PRINT NAME	
· Inflire				Taylor Lombard	
230169 08/08/2025	ON DATE			TELEPHONE NUMBER (417) 451-8300	
Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office by mail, fax, or email.					

AS IV Serial no: 119729
Version no: 532C

TEST RECORD - REPRINT

TEST RECORD 00166

Temp Date Time 210L

Air Blank: 01/22/25 11:08 .000
Calibration Check: 21 01/22/25 11:08 .102

Subject Name

7est /
Operator Name, I.D.

Taylor (omband 730169
Location

208 W Coler St

Necsho, Mo 64850

AS IV Serial no: 119729
Version no: 532C

TEST RECORD 00168

Temp Date Time 210L

Air Blank: 01/22/25 12:01 .000
Calibration Check: 19 01/22/25 12:01 .102

Subject Name

Test 3
Operator Name, I.D.

Teylor Lamband 230169
Location

ZOS W Coler St

Necsho Mo 64850

AS IV Serial no: 119729
Version no: 532C

TEST RECORD 00167

Temp Date Time 210L

Air Blank:
01/22/25 11:28 .000
21 01/22/25 11:28 .101

Subject Name

Test
Subject I.D.

Test 2

Operator Name. I.D.

Taylor Lombor W 730149

Location

208 W Coler 54

Neoshoy Mo 64850

AS IV Serial no: 119729
Version no: 532C

TEST RECORD 00169
Temp Date Time 210L

VOID: RFI
12 01/22/25 12:03

Subject Name

Test
Subject I.D.

RFT
Operator Name, I.D.

Testor Lombors 230169

ZOSW Coler St

Wicosho, MO 64851



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 24310 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on August 28, 2024, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1209% (w/vol) ethyl alcohol. The expiration date for this lot number is August 27, 2026 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN03072301 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES **BREATH ALCOHOL PROGRAM**



PERMIT TYPE II

TAYLOR LOMBARD

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the algoholic content of blood from a sample of expired air. Permit issued under the provisions of sections

577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo. DATE ___8/8/2023 DIRECTOR OF STATE PUBLIC HEALTH LABORATORY NUMBER 230169 Daves J. Nielselson **EXPIRES 8/8/2025** DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES MO 680-0771 (6-10) LAB-1 (HB-10)



The named cardholder is suihenteed to operate an evidential breath alcohol ristrament for the determination of the alcohollo content in breath form of expired a

Operator LOMBAR Pornit No 230169 Date Issued 8/9/2023 LOMBARD, TAYLOR

Date Expires 8/8/2025

